




OPTIBELT

# TECHNICAL MANUAL

## RIBBED BELT DRIVES



INCLUDING PULLEYS  
AND BUSHES



# TECHNICAL MANUAL

## RIBBED BELT DRIVES



This manual contains all relevant technical information as well as the method for calculating drives with optibelt RB ribbed belts and optibelt RBS ribbed belt pulleys for mechanical engineering. The Optibelt range for ribbed belt drives is based on the standards ISO 9982, RMA/MPTA IP-26 and DIN 7867.

Our applications engineers would be pleased to give advice about using these drive systems and will work together with you to solve your drive problems. This service is of course free of charge.

It is especially important for large-scale series to take advantage of this service which will find the best possible solution for your requirements using state-of-the-art computer programs.

**OPTIBELT EUROPE**

**OPTIBELT AFRICA**

**OPTIBELT AMERICA**

Optibelt's partners can  
be found in most countries  
throughout the world



**Optibelt GmbH**  
[www.optibelt.com](http://www.optibelt.com)



**Optibelt Nederland B.V.**  
[www.optibelt.nl](http://www.optibelt.nl)



**Optibelt GmbH**  
[www.optibelt.be](http://www.optibelt.be)



**Optibelt Österreich GmbH**  
[www.optibelt.at](http://www.optibelt.at)



**Optibelt Polska Sp. z o.o.**  
[www.optibelt.pl](http://www.optibelt.pl)



**Optibelt Hungary Kft.**  
[www.optibelt.hu](http://www.optibelt.hu)



**Optibelt (Canada) Inc.**  
[www.optibelt.ca](http://www.optibelt.ca)



**Optibelt de México**  
[www.optibelt.mx](http://www.optibelt.mx)



**Optibelt do Brasil Ltda.**  
[www.optibelt-br.com](http://www.optibelt-br.com)



**Optibelt Indonesia**  
[www.optibelt.co.id](http://www.optibelt.co.id)



**Optibelt Asia Pacific Pte. Ltd.**  
[www.optibelt.sg](http://www.optibelt.sg)



**Optibelt Power Transmission (Shanghai) Co., Ltd.**  
[www.optibelt.cn](http://www.optibelt.cn)

## OPTIBELT ASIA

## OPTIBELT AUSTRALIA

 Optibelt AG  
[www.optibelt.ch](http://www.optibelt.ch)

 Optibelt Güç Aktarma Ekipmanları San. Ve Tic Ltd. Sti.  
[www.optibelt.com.tr](http://www.optibelt.com.tr)

 Optibelt Colombia S.A.S.  
[www.optibelt.com](http://www.optibelt.com)

 Optibelt Thailand  
[www.optibelt.co.th](http://www.optibelt.co.th)

 Optibelt (UK) Ltd.  
[www.optibelt.co.uk](http://www.optibelt.co.uk)

 OOO „Optibelt Power Transmission“  
[www.optibelt.ru](http://www.optibelt.ru)

 Optibelt Power Transmission India Pvt. Ltd.  
[www.optibelt.in](http://www.optibelt.in)

 Optibelt Vietnam  
[www.optibelt.vn](http://www.optibelt.vn)

 Optibelt France SAS  
[www.optibelt.fr](http://www.optibelt.fr)

 Optibelt Finland Oy  
[www.optibelt.fi](http://www.optibelt.fi)

 Optibelt Australia Pty Ltd.  
[www.optibelt.com.au](http://www.optibelt.com.au)

 Optibelt AG  
[www.optibelt.it](http://www.optibelt.it)

 Optibelt Skandinaviska AB  
[www.optibelt.se](http://www.optibelt.se)

 Optibelt TRANZ Corp.  
[www.optibelt.co.nz](http://www.optibelt.co.nz)

 Optibelt España, S.A.  
[www.optibelt.es](http://www.optibelt.es)

 Optibelt Corporation  
[www.optibelt.us](http://www.optibelt.us)

 Optibelt Philippines  
[www.optibelt.ph](http://www.optibelt.ph)

# RIBBED BELTS AND RIBBED BELT PULLEYS



## Ribbed Belts

### 1/7/8 **optibelt RB**

Ribbed Belts, Profile PJ  
Lengths: 280-2489 mm  
Other dimensions on request

### 2/6 **optibelt RB**

Ribbed Belts, Profile PK  
Lengths: 559-2845 mm  
Other dimensions on request

### 3 **optibelt RB**

Ribbed Belts, Profile PH  
Lengths: 559-2155 mm  
Other dimensions on request

### 4 **optibelt RB**

Ribbed Belts, Profile PM  
Lengths: 2286-15266 mm  
Other dimensions on request

### 5 **optibelt RB**

Ribbed Belts, Profile PL  
Lengths: 954-6096 mm  
Other dimensions on request

### **optibelt RB**

Elastic Ribbed Belts  
Profiles: EPH, EPJ on request (not shown)

## Ribbed Belt Pulleys

### A **optibelt RBS**

Ribbed Belt Pulleys for Cylindrical Bore

### B **optibelt RBS**

Ribbed Belt Pulleys for Taper Bushes

### B **optibelt RBS**

Ribbed Belt Pulleys with Taper Bushes

### B **optibelt RBS**

Ribbed Belt Pulleys with Taper Bushes

# CONTENTS



Introduction .....	1
Distribution Organisation of the Arntz Optibelt Group .....	2
Ribbed Belts and Ribbed Belt Pulleys .....	4

## PRODUCT DESCRIPTION

Standard Range optibelt RB Ribbed Belts.....	7
Elastic optibelt ERB Ribbed Belts / Special Designs .....	8
Characteristics – Application Areas	
Elastic optibelt ERB Ribbed Belts / Roller Conveyor .....	9
Special Designs .....	10-11
Automotive Drives optibelt CAR POWER RBK .....	12

## STANDARD RANGE

Ribbed Belts .....	13-14
--------------------	-------

## DRIVE DESIGN

Abbreviations Used in Formulae .....	15
Optibelt Power Rating $P_N$ – Arc of Contact Correction Factor $c_1$ .....	16
Belt Length Correction Factor $c_3$ .....	17-18
Minimum Allowance $x/y$ above and below Drive Centre Distance $a_{nom}$ .....	19
Drive Service Factor $c_2$ .....	20
A Guide to Selecting Ribbed Belt Profiles .....	21
Formulae and Calculation Example .....	22-24
Drive Design – optibelt CAP .....	25

## POWER RATINGS

optibelt RB Ribbed Belts, Profile PH .....	26
optibelt RB Ribbed Belts, Profile PJ .....	27
optibelt RB Ribbed Belts, Profile PK .....	28
optibelt RB Ribbed Belts, Profile PL .....	29
optibelt RB Ribbed Belts, Profile PM .....	30

# CONTENTS



## SPECIAL DRIVES

V-Flat Drives .....	31-32
Tension/Guide Idlers .....	33-34

## RIBBED BELT PULLEYS

Measuring Pulleys – Length Measuring Conditions to DIN 7867 / ISO 9982 .....	35
Dimensions to DIN 7867 / ISO 9982 .....	36
Standard Range optibelt TB Taper Bushes .....	37
Ribbed Belt Pulleys for Taper Bushes, Profile PJ .....	38-41
Ribbed Belt Pulleys for Taper Bushes, Profile PL .....	42-46
Ribbed Belt Pulleys for Cylindrical Bore, Profile PJ .....	47

## DESIGN HINTS

Ribbed Belt Tension .....	48-51
Frequency Meter / Tension Tester optibelt TT .....	52
Frequency Meter / Tension Tester optibelt TT LINE .....	53
Determining the Static Shaft Loading / Shaft Loading under Dynamic Conditions .....	54
Length Tolerances – Installation and Maintenance .....	55
Ribbed Belt Widths .....	56
Problems – Causes – Remedies .....	57-58
Additional Range	
optibelt TT Frequency Meter .....	59
optibelt LASER POINTER II .....	59
Optibelt Pulley Groove Gauges .....	59
Data Sheet for Drive Calculation/Checking .....	60-61


# PRODUCT DESCRIPTION

## STANDARD RANGE optibelt RB RIBBED BELTS



### Construction

Optibelt ribbed belts consist of:



- 1 Belt top surface: wear resistant polychloroprene rubber compound
- 2 Tension cord: low-stretch polyester cord embedded in an adhesive rubber compound
- 3 Base compound: parallel V-shaped ribs of a wear resistant rubber compound

### Characteristics

- Combines the high flexibility of the flat belt with the high power transmission capability of the traditional V-belts
- Small pulley diameters
- Large speed ratios possible
- Good frictional power transmission and high power transmission capability
- Insensitive to torque impulses and short-term overloading

### Applications

#### Profile PH

Domestic appliances, medical appliances, machine tools, small conveyors, conveyor belt, paper transport machines

#### Profile PJ

Small compressors, cement mixers, white goods, small tools

#### Profile PK

Fans, air conditioning, concrete saws, wood saws, industrial washing machines






#### Profile PL

Compressors (> 30 kW), industrial washing machines

#### Profile PM

Paper industry, agricultural machines (silage cutter), sugar cane cutter

### Standard Profiles




# PRODUCT DESCRIPTION

## ELASTIC optibelt ERB RIBBED BELTS / SPECIAL DESIGNS



### Construction

The elastic ribbed belts of profiles EPH, EPJ and EPK consist of:



The elastic ribbed belt is characterised by the highly individual options for designing and adapting it for different drive solutions particularly for fixed distances between centres. In addition, the running properties of the ribbed belt can be further optimised by additional refinement of the surface on the ribbed side.

### Advantages and Characteristics

- Assembly is possible on fixed centres with no need for adjustment for belt tensioning
- Good damping performance and shock load resistance due to high elasticity of belt
- Maintenance-free and no retensioning required
- Easy assembly in service areas
- Allows individual design of tension and elongation characteristics

### Dimensions

Belt lengths depend on the profile, from 250 mm to 2500 mm.




- Ribbed belt – electrically conductive on request
- Ribbed belt – high voltage resistant on request
- PAK optimised – on request

### Ribbed Belt Pulleys

Extensive standard range (see range list); special pulleys on request.

Please contact our Applications Engineering Department for individual drive solutions.

### Special Versions



# PRODUCT DESCRIPTION

## CHARACTERISTICS – APPLICATION AREAS

### ELASTIC optibelt ERB RIBBED BELTS / ROLLER CONVEYOR



#### Retensioning Not Necessary – Extended Service Intervals – Optimal Damping of Drive Vibrations

Recently, some roller conveyor belt systems have been equipped with elastic ribbed belts of the model optibelt ERB. Those belts keep the single rolls moving and do not need any retensioning in continuous industrial operation. Thus, they are virtually maintenance-free. For this reason, elastic ribbed belts are now also deployed in transport technology.

The advantages are more than obvious as elastic ribbed belts do not have to be run in in the first place and do not therefore need to be retensioned. optibelt ERB belts gain the required tension due to a higher basic tension and the systematic settling characteristics of the belts. Retensioning can be dispensed with as a result.



Optibelt ribbed belts offer many advantages for end users, too, such as manufacturing companies that use roller conveyor belts as a means of conveyance to the warehouse. Thanks to the belt, the vibrations of the drive are better absorbed, resulting in a smoothly running, extremely low-vibration roller drive. This leads to a minimised wear of the components and extends the operational life of the individual roller bearings. On the other hand, less vibration means less noise and thus improved working conditions.

Given these obvious advantages for users and manufacturers, there is only one definite goal concerning the optimisation of many roller conveyor belt drives: the changeover from round profile belts and timing belts to elastic ribbed belts made by Optibelt.



# PRODUCT DESCRIPTION

## SPECIAL DESIGNS



# PRODUCT DESCRIPTION

## SPECIAL DESIGNS

### OPTIBELT RIBBED BELTS WITH ARAMID TENSILE REINFORCEMENT

### OPTIBELT RIBBED BELTS WITH SPECIAL COATINGS



#### Ribbed Belts with Aramid Tensile Reinforcement

The extremely low-stretch aramid tension cords stand out in comparison with conventional tensile reinforcement such as polyester. They have almost twice the breaking strength of fibres of the same thickness. Despite their high strength, the fibre is flexible and has sufficient elasticity to cushion shocks and vibrations.

Optibelt ribbed belts with aramid tensile reinforcement are for use where

- maximum power transmission is called for,
- overall widths are restricted,
- minimum adjustment range is available for installation and tensioning and
- high temperature impacts are present.

Ribbed belts with aramid tensile reinforcement are ideal for use in drives with heavy wear in mechanical engineering, special-purpose engineering, agricultural engineering and in garden tools.

It is not possible to go into the entire range of criteria in this manual. Please get in touch with our applications engineers for in-depth advice.

#### Profiles

PK/PL with 8M or 14M surface

#### Pulleys

Timing belt pulleys HTD or RPP and ribbed belt pulleys profile PK and PL

#### Applications

The optibelt OMEGA timing belt with additional ribbed PK belt profile on the back cover of the belt is perfect for use in mills, e.g. food, corn, fruit and flour mills, where the back pulley has a reversible direction and slipping is necessary when the drive blocks.

#### Advantage

The rubber compound filled with aramid fibres is very wear resistant. The back cover of the PK profile is moulded in one operation with the timing belt.

#### Optibelt Ribbed Belts with Special Coatings



Due to the huge variety of coatings and finishing possibilities plus the properties of the ribbed belt, Optibelt has developed innovative solutions in the field of conveying technology. Optibelt ribbed belts can be provided with an additional top surface coating. The coating is applied in a special adhesive procedure.

Ribbed belts with a patterned top surface can be used in place of expensive conveyor belts. They run singly or with several belts adjacent to each other and transport the goods to be conveyed horizontally and at up and down gradients. Vertical conveyance is possible if the ribbed belts are arranged back to back and the media conveyed is pressed together between the two belts.

#### Applications

Examples of some of the many successful uses for Optibelt ribbed belts with coatings include:

- Conveying doors, parts of cabinets, veneer and plastic panels for wood-working
- Conveying car body parts and sharp-edged sheet metal panels in the automotive industry
- Conveying cartons and boxes in the packaging industry



# PRODUCT DESCRIPTION

## AUTOMOTIVE DRIVES optibelt CAR POWER RBK



New engine designs demand more and more space saving. It is not unusual to encounter small pulley diameters and limited drive widths. Being extremely elastic and dimensionally stable, Optibelt ribbed belts can adapt to the respective drive geometry. They are flexible enough to find their path as a serpentine drive through the motor labyrinth. The flexible ribbed belt is extremely quiet and supple in its job of controlling the power train.

Optibelt ribbed belts drive ancillary units in cars, commercial vehicles and buses. They reduce vibration and give the generator, air-conditioning compressor, and the power steering pump the right spin.

### Characteristics

- Large speed ratios
- High power transmission
- Minimum slip
- Largely oil and temperature resistant
- Vibration free and quiet
- Extraordinarily resilient

### Profiles

PJ, PK, DPK


### Dimensions

2 PK	from	786 to 905 mm
3 PK	from	550 to 1285 mm
4 PK	from	560 to 1520 mm
5 PK	from	625 to 2055 mm
6 PK	from	675 to 2680 mm
7 PK	from	870 to 2355 mm
8 PK	from	800 to 2605 mm
9 PK	from	1200 to 4145 mm
10 PK	from	1108 to 2063 mm
11 PK	from	1515 to 2055 mm
12 PK	from	1165 to 2500 mm
3 EPK	from	806 to 885 mm
4 EPK	from	711 to 1102 mm
5 EPK	from	690 to 926 mm
6 EPK	from	691 to 1873 mm
6 DPK	from	1188 to 1853 mm
7 DPK	from	1360 to 1400 mm

Additional sizes on request.


### Applications

Use in automotive engineering to drive the power train



# STANDARD RANGE

## RIBBED BELTS



Profile		PH	PJ	PK	PL	PM
Rib pitch	s [mm]	1.60	2.34	3.56	4.70	9.40
Belt thickness	$\approx h$ [mm]	2.50	3.30	4.60	7.00	13.00
Belt speed	$\approx v$ [m/s]	60	60	50	40	30
Minimum pulley diameter	$d_{b\ min}$ [mm]	13	20	45	75	180
Effective line difference	$h_b$	0.80	1.25	1.60	3.50	5.00

Profile PH				Profile PJ				
Effective length $L_b$ [mm]	Effective length $L_b$ [inch]							
698	27.50	1397	55.00	280	11.00	1130	44.50	1915
735	28.90	1439	56.70	330	13.00	1150	45.30	1930
762	30.00	1475	58.10	356	14.00	1168	46.00	1956
813	32.00	1600	63.00	362	14.30	1194	47.00	1965
858	33.80	1854	73.00	381	15.00	1200	47.30	1981
864	34.00	1895	74.60	406	16.00	1222	48.10	1992
886	34.90	1915	75.40	414	16.30	1244	49.00	2083
955	37.60	1930	76.00	432	17.00	1262	49.70	2155
965	38.00	1956	77.00	457	18.00	1270	50.00	2210
975	38.40	1992	78.40	483	19.00	1285	50.60	2337
990	39.00	2083	82.00	508	20.00	1301	51.20	2489
1016	40.00	2155	84.80	559	22.00	1309	51.50	
1080	42.50			584	23.00	1316	51.80	
1092	43.00			610	24.00	1321	52.00	
1096	43.10			660	26.00	1333	52.50	
1168	46.00			711	28.00	1355	53.40	
1194	47.00			723	28.50	1371	54.00	
1200	47.20			737	29.00	1397	55.00	
1222	48.10			762	30.00	1428	56.20	
1230	48.40			813	32.00	1439	56.70	
1262	49.70			836	32.90	1475	58.10	
1270	50.00			864	34.00	1549	61.00	
1285	50.60			914	36.00	1600	63.00	
1290	50.80			955	37.60	1651	65.00	
1301	51.20			965	38.00	1663	65.50	
1309	51.50			1016	40.00	1752	69.00	
1316	51.80			1092	43.00	1780	70.00	
1321	52.00			1105	43.50	1854	73.00	
1333	52.50			1110	43.70	1895	74.60	
1371	54.00			1123	44.20	1910	75.20	

**Note:** Individually designed ribbed belts may deviate from the standard composition.  
Please contact our Applications Engineering Department!

Non standard lengths on request.  
Maximum number of ribs: Please contact our Applications Engineering Department.  
**Profile PH is a non stock item.**

**Ordering example:**  
For a five-rib ribbed belt with profile PJ  
with an effective length 660 L<sub>b</sub>: optibelt RB 5 PJ 660 L<sub>b</sub>

# STANDARD RANGE

## RIBBED BELTS



Profile PK				Profile PL		Profile PM	
Effective length L <sub>b</sub> [mm]	Effective length L <sub>b</sub> [inch]	Effective length L <sub>b</sub> [mm]	Effective length L <sub>b</sub> [inch]	Effective length L <sub>b</sub> [mm]	Effective length L <sub>b</sub> [inch]	Effective length L <sub>b</sub> [mm]	Effective length L <sub>b</sub> [inch]
630•	24.80	1290•	50.80	2515•	99.00	954	37.50
648	25.50	1321•	52.00	2845•	112.00	991	39.00
698	27.50	1330	52.40			1075	42.30
730	28.70	1345	53.00			1194	47.00
775	30.50	1371•	54.00			1270	50.00
800	31.50	1397•	55.00			1333	52.50
812	32.00	1439•	56.70			1371	54.00
830	32.70	1460	57.50			1397	55.00
865	34.00	1520	59.80			1422	56.00
875	34.50	1560	61.40			1562	61.50
890	35.00	1570	61.80			1613	63.50
913	36.00	1600•	63.00			1664	65.50
920	36.20	1655	65.20			1715	67.50
940	37.00	1690	66.50			1764	69.50
954	37.60	1755	69.10			1803	71.00
962	37.80	1854•	73.00			1841	72.50
990	39.00	1885	74.20			1943	76.50
1015	40.00	1930•	76.00			1981	78.00
1080	42.50	1956•	77.00			2020	79.50
1090	43.00	1980	78.00			2070	81.50
1125	44.30	2030	79.90			2096	82.50
1150	45.30	2050	80.70			2134	84.00
1165	45.90	2080	82.00			2197	86.50
1190	46.80	2120	83.50			2235	88.00
1200•	47.20	2145	84.40			2324	91.50
1222•	48.10	2170	85.40			2362	93.00
1230•	48.40	2235•	88.00			2476	97.50
1245	49.00	2255	88.80			2515	99.00
1270•	50.00	2362•	93.00			2705	106.50
1285•	50.60	2460	96.90			2743	108.00
						2845	112.00
						2895	114.00
						2921	115.00
						2997	118.00
						3086	121.50
						3124	123.00
						3289	129.50
						3327	131.00
						3492	137.50
						3696	145.50
						4051	159.50
						4191	165.00
						4470	176.00
						4622	182.00
						5029	198.00
						5385	212.00
						6096	240.00

**Note:** Individually designed ribbed belts may deviate from the standard composition.  
Please contact our Applications Engineering Department!

Non standard lengths on request.  
Maximum number of ribs: Please contact our Applications Engineering Department.  
• non stock items


# DRIVE DESIGN

## ABBREVIATIONS USED IN FORMULAE



$a$	= Drive centre distance
$a_{\text{nom}}$	= Drive centre distance, calculated with a standard belt length
$c_1$	= Arc of contact correction factor
$c_2$	= Drive service factor
$c_3$	= Belt length correction factor
$d_{bg}$	= Effective diameter of large pulley
$d_{bk}$	= Effective diameter of small pulley
$d_{b1}$	= Effective diameter of driver pulley
$d_{b2}$	= Effective diameter of driven pulley
$E$	= Belt deflection per 100 mm span length
$E_a$	= Belt deflection for a given span length
$f$	= Load used to set belt tension per rib
$h$	= Belt thickness
$h_b$	= Effective line difference
$i$	= Speed ratio
$k$	= Constant for calculation of centrifugal force
$L$	= Span length
$L_{bsi}$	= Standard belt effective length
$L_{bth}$	= Calculated belt effective length

[mm]	$n_g$ = Speed of large pulley	[rpm]
[mm]	$n_k$ = Speed of small pulley	[rpm]
[mm]	$n_1$ = Speed of driver pulley	[rpm]
[mm]	$n_2$ = Speed of driven pulley	[rpm]
	$P$ = Motor or normal running power	[kW]
[mm]	$P_B$ = Design power	[kW]
[mm]	$P_N$ = Power rating per rib	[kW]
[mm]	$s$ = Drive span length	[mm]
[mm]	$S_a$ = Minimum static shaft loading	[N]
[mm]	$T$ = Minimum static belt tension per rib	[N]
[mm]	$v$ = Belt speed	[m/s]
	$x$ = Minimum adjustment required above drive centre distance $a_{\text{nom}}$ to compensate for tensioning and retensioning	[mm]
[mm]	$y$ = Minimum adjustment required below drive centre distance $a_{\text{nom}}$ to allow for belt installation	[mm]
	$z$ = Number of ribs	
[mm]	$\alpha$ = Angle of belt run = $90^\circ - \frac{\beta}{2}$	°[degrees]
[mm]	$\beta$ = Arc of contact on small pulley	°[degrees]
[mm]		



# DRIVE DESIGN

## OPTIBELT POWER RATING $P_N$ – ARC OF CONTACT CORRECTION FACTOR $c_1$



Optibelt power ratings  $P_N$  shown in tables 5 to 9 are based on internationally recognised formulae. These formulae contain material constants which must be used in accordance with the practices of the individual manufacturers. The  $P_N$  power rating formula is based on a specific tension ratio between the tight and slack sides of the belt. The  $P_N$  power rating tables refer to the smallest loaded pulley in the drive. The belt power ratings  $P_N$  from the tables are given for:

- the effective diameter of small pulley  $d_{bk}$
- the speed of small pulley  $n_k$
- speed ratio  $i$
- the arc of contact of the belt on small pulley  $\beta = 180^\circ$
- the ideal belt length for the particular belt profile

From the given drive data, the power rating per rib can be found which must then be modified by application of the arc of contact correction factor  $c_1$  and belt length correction factor  $c_3$ .

Intermediate values can be found by linear interpolation.

The arc of contact correction factor  $c_1$  corrects the power rating  $P_N$  when the arc of contact of the belt is smaller than  $180^\circ$ , since the  $P_N$  value of the arc of contact  $\beta = 180^\circ$  was determined on the small pulley  $d_{bk}$ .

**Table 1**

$d_{bg} - d_{bk}$ $a_{nom}$	$\beta \approx$	$c_1$
0	$180^\circ$	1.00
0.05	$177^\circ$	1.00
0.10	$174^\circ$	1.00
0.15	$171^\circ$	0.99
0.20	$168^\circ$	0.99
0.25	$165^\circ$	0.99
0.30	$162^\circ$	0.99
0.35	$160^\circ$	0.99
0.40	$156^\circ$	0.98
0.45	$153^\circ$	0.98
0.50	$150^\circ$	0.98
0.55	$147^\circ$	0.97
0.60	$144^\circ$	0.97
0.65	$141^\circ$	0.97
0.70	$139^\circ$	0.96
0.75	$136^\circ$	0.96
0.80	$133^\circ$	0.95
0.85	$130^\circ$	0.95
0.90	$126^\circ$	0.94
0.95	$123^\circ$	0.94
1.00	$119^\circ$	0.93
1.05	$115^\circ$	0.92
1.10	$112^\circ$	0.92
1.15	$109^\circ$	0.91
1.20	$106^\circ$	0.90
1.25	$103^\circ$	0.89
1.30	$100^\circ$	0.89
1.35	$96^\circ$	0.87
1.40	$92^\circ$	0.86
1.45	$88^\circ$	0.85
1.50	$84^\circ$	0.83
1.55	$80^\circ$	0.82
1.60	$77^\circ$	0.80

Intermediate lengths can be calculated by linear interpolation!

# DRIVE DESIGN

## BELT LENGTH CORRECTION FACTOR $c_3$



The belt length correction factor  $c_3$  takes into account the flex rate in the particular belt profile in relationship to a standard effective length.

This results in the following relationships:

ribbed belt length used > standard effective length  $c_3 > 1.0$

ribbed belt length used = standard effective length  $c_3 = 1.0$

ribbed belt length used < standard effective length  $c_3 < 1.0$

$$c_3 = 1 + \left[ \left( \frac{L_b}{L_{bo}} \right)^{0.09} - 1 \right] \cdot 2.4$$

$L_b$  = ribbed belt length used

$L_{bo}$  = standard effective length

**Table 2**

Profile PH				Profile PJ			
Effective length $L_b$ [mm]	$c_3$	Effective length $L_b$ [mm]	$c_3$	Effective length $L_b$ [mm]	$c_3$	Effective length $L_b$ [mm]	$c_3$
559	0.96	1956	1.19	280	0.74	1309	1.05
698	0.96	1992	1.20	330	0.76	1316	1.05
735	0.97	2083	1.21	356	0.78	1321	1.05
762	0.98	2155	1.22	362	0.78	1333	1.05
<b>813</b>	<b>1.00</b>			381	0.79	1355	1.06
858	1.01			406	0.80	1371	1.06
864	1.01			414	0.81	1397	1.06
886	1.01			432	0.82	1428	1.07
914	1.02			457	0.83	1439	1.07
955	1.03			483	0.84	1475	1.08
965	1.03			508	0.85	1549	1.09
975	1.03			559	0.87	1600	1.10
990	1.03			584	0.88	1651	1.10
1016	1.04			610	0.89	1663	1.10
1080	1.06			660	0.90	1752	1.12
1092	1.06			711	0.92	1780	1.12
1096	1.06			723	0.92	1854	1.13
1168	1.07			762	0.93	1895	1.13
1194	1.08			813	0.95	1910	1.14
1200	1.08			836	0.95	1915	1.14
1222	1.08			864	0.96	1930	1.14
1230	1.09			914	0.97	1956	1.14
1262	1.09			955	0.98	1965	1.14
1270	1.09			965	0.98	1981	1.14
1285	1.10			<b>1016</b>	<b>1.00</b>	1992	1.14
1290	1.10			1092	1.01	2083	1.16
1301	1.10			1105	1.01	2155	1.17
1309	1.10			1110	1.01	2210	1.17
1316	1.10			1123	1.02	2337	1.18
1321	1.10			1130	1.02	2489	1.20
1333	1.10			1150	1.02		
1371	1.11			1168	1.03		
1397	1.11			1194	1.03		
1439	1.12			1200	1.03		
1475	1.13			1222	1.04		
1600	1.15			1244	1.04		
1854	1.18			1262	1.04		
1895	1.18			1270	1.04		
1915	1.19			1285	1.05		
1930	1.19			1301	1.05		

Additional sizes on request.

# DRIVE DESIGN

## BELT LENGTH CORRECTION FACTOR $c_3$



Table 2

Profile PK				Profile PL				Profile PM	
Effective length $L_b$ [mm]	$c_3$	Effective length $L_b$ [mm]	$c_3$	Effective length $L_b$ [mm]	$c_3$	Effective length $L_b$ [mm]	$c_3$	Effective length $L_b$ [mm]	$c_3$
559	0.78	1956	1.04	954	0.83	4051	1.14	2286	0.87
630	0.81	1980	1.05	991	0.84	4191	1.15	2388	0.88
648	0.81	2030	1.05	1075	0.86	4470	1.16	2515	0.89
698	0.82	2050	1.05	1194	0.88	4622	1.17	2693	0.91
730	0.84	2080	1.06	1270	0.89	5029	1.19	2832	0.92
775	0.85	2120	1.06	1333	0.90	5385	1.21	2921	0.92
800	0.85	2145	1.06	1371	0.91	6096	1.24	3010	0.93
812	0.86	2170	1.07	1397	0.91			3124	0.94
830	0.86	2235	1.09	1422	0.91			3327	0.95
865	0.87	2362	1.09	1562	0.93			3531	0.96
875	0.87	2460	1.09	1613	0.94			3734	0.98
890	0.88	2515	1.10	1664	0.95			<b>4089</b>	<b>1.00</b>
913	0.88	2743	1.12	1715	0.95			<b>4191</b>	<b>1.00</b>
920	0.88	2845	1.13	1764	0.96			4470	1.01
940	0.89			1803	0.96			4648	1.02
954	0.89			1841	0.97			5029	1.04
962	0.89			1943	0.98			5410	1.06
990	0.90			1981	0.98			6121	1.08
1015	0.90			2020	0.99			6883	1.11
1080	0.92			2070	0.99			7646	1.13
1090	0.91		<b>2096</b>	<b>1.00</b>				8408	1.16
1100	0.92		<b>2134</b>	<b>1.00</b>				9169	1.18
1125	0.93		2197	1.01				9931	1.19
1150	0.93		2235	1.01				10693	1.21
1165	0.93		2324	1.02				12217	1.24
1190	0.94		2362	1.02				13741	1.27
1200	0.94		2476	1.03				15266	1.30
1222	0.94		2515	1.03					
1230	0.94		2705	1.05					
1245	0.95		2743	1.05					
1270	0.95		2845	1.06					
1285	0.95		2895	1.07					
1290	0.95		2921	1.07					
1321	0.96		2997	1.07					
1330	0.96		3086	1.08					
1345	0.96		3124	1.08					
1371	0.97		3289	1.09					
1397	0.97		3327	1.10					
1439	0.98		3492	1.11					
1460	0.98		3696	1.12					
1520	0.99								
1560	0.99								
<b>1570</b>	<b>1.00</b>								
<b>1600</b>	<b>1.00</b>								
1655	1.01								
1690	1.01								
1755	1.02								
1854	1.03								
1885	1.04								
1930	1.04								

Additional sizes on request.

# DRIVE DESIGN


## MINIMUM ALLOWANCE x/y ABOVE AND BELOW DRIVE CENTRE DISTANCE $a_{nom}$



Table 3

Effective length $L_b$ [mm]	Minimum allowance x [mm] – for tensioning and retensioning	Minimum allowance y [mm] – for ease of fitting				
		Profile PH	Profile PJ	Profile PK	Profile PL	Profile PM
$\leq 500$	10	10	10	—	—	—
$> 500 \leq 1000$	15	15	15	20	25	—
$> 1000 \leq 1500$	20	15	15	20	25	—
$> 1500 \leq 2000$	25	15	15	20	25	—
$> 2000 \leq 2500$	30	20	20	20	25	40
$> 2500 \leq 3000$	35	20	20	25	30	40
$> 3000 \leq 4000$	45	—	—	25	30	45
$> 4000 \leq 5000$	55	—	—	30	35	45
$> 5000 \leq 6000$	65	—	—	30	35	50
$> 6000 \leq 7500$	85	—	—	—	—	55

### Minimum Allowance



# DRIVE DESIGN

## DRIVE SERVICE FACTOR $c_2$



The drive service factor  $c_2$  takes into account the length of time the drive is operational in a 24 hour period and the type of driver and driven units. It applies exclusively to two pulley drives. It does not take into account other working conditions, such as drives with tension, guide and idler pulleys. Pages 33 to 34 give the design bases for drives with more than two pulleys. Extreme operating conditions such as aggressive dust, particularly high temperatures or the influence of various media are **not** considered. Since it is practically impossible to condense every possible combination of drive unit/driven machine/operating conditions into a standard-compliant form the drive service factors are **guide values**. In special cases

e.g. high starting load (direct starting of fans), drives with high starting frequency, unusual shock loading, or the regular acceleration/deceleration of mass, the load factor should be increased.

### Typical value:

**Where the starting load is more than 1.8 times the standard running load, the value should be divided by 1.5 to obtain the minimum drive service factor  $c_2$ ; example: starting load factor  $M_A = 3.0$ ;  $c_2$  selected as 2.0. Where the application is especially problematical please consult our applications engineers.**

**Table 4**

Types of Driven Machine		Types of Prime Mover					
		Hours per day duty					
		10 and under	over 10 to 16	over 16	10 and under	over 10 to 16	over 16
Consistent duty, only low masses to be accelerated	Agitators for liquids with uniform consistency, generators up to 0.05 kW, small conveyor belts for lightweight material, fans up to 0.05 kW, rotary pumps up to 0.05 kW	1.1	1.1	1.2	1.1	1.2	1.3
Consistent light duty operation, low masses to be accelerated	Conveyor belts for lightweight material, fans from 0.06 to 0.1 kW, rotary pumps from 0.06 to 0.1 kW	1.1	1.2	1.3	1.2	1.3	1.4
Inconsistent duty operation, medium-sized masses to be accelerated	Vibrating screens, pit fans, agitators for liquids with fluctuating consistency, compressors, screw presses, woodworking machinery, conveyor belts for heavy material, elevators, conveyor belts, fans above 0.8 kW, drills, milling machines, grinding machines, light lathes, bakery machinery, circular spinning frames, rotary pumps above 0.11 kW, laundry machinery	1.2	1.3	1.4	1.3	1.4	1.5
Inconsistent medium duty, medium-sized shocks and masses to be accelerated	Kneaders, mills, mixers, pumps, drying drums, general milling equipment, centrifuges, agitators for plastic materials with fluctuating consistency, bucket conveyors, centrifugal fans, parallel planing machines, weaving looms	1.3	1.4	1.5	1.4	1.5	1.6
Inconsistent duty operation, high shocks and masses to be accelerated	Paper making machinery, plate conveyors, slag mills, calenders, drilling rigs, heavy duty lathes, punches, shears, draw benches, piston pumps up to 2 cylinders	1.4	1.5	1.6	1.5	1.7	1.8
Inconsistent duty operation, extra high masses to be accelerated, extra high shocks	Dredgers, heavy duty grinders, rolling mills, mixers, sawmills, calenders	1.6	1.7	1.8	1.6	1.8	2.0

# DRIVE DESIGN

## A GUIDE TO SELECTING RIBBED BELT PROFILES



By using the following diagram and considering economy and size it is possible to determine the best ribbed belt profile. Optimum utilisation of power and efficiency is achieved by the selection of the largest possible pulley diameter in relation to the profile used. The limits to the permissible circumferential speeds for ribbed belts must be observed:

Profile PH  $v_{max} = 60$  m/s

Profile PJ  $v_{max} = 60$  m/s

Profile PK  $v_{max} = 50$  m/s

Profile PL  $v_{max} = 40$  m/s

Profile PM  $v_{max} = 35$  m/s


Please contact our Applications Engineering Department in the case of higher circumferential speeds.

Experience has shown that minimum pulley diameters should be avoided. These drives require a larger number of ribs and consequently broad pulleys. As a result, they are cost-intensive. The ribbed belt width should not be larger than the effective diameter of the small pulley.

In such borderline cases the use of the next smaller belt profile on similar pulley diameters will often save both cost and space.

A check is also advisable if the point of interprofile in the selection diagram used lies in the boundary areas between two profiles.

**Diagram 1**



# DRIVE DESIGN

## FORMULAE AND CALCULATION EXAMPLE



### Prime Mover




Electric motor  
 $P = 13 \text{ kW}$   
 $n_1 = 2440 \text{ rpm}$   
 Start up: direct  
 Starting torque:  $M_A = 2.7 \text{ Nm}$

### Drive Conditions

Operational hours per day: 8 hours  
 Number of starts: 20 per day  
 Normal ambient temperature,  
 no exposure to oil and water

### Driven Machine



Drive centre distance: between  
 350 and 400 mm acceptable  
 Effective diameter of driver pulley:  
 $d_{b1} \leq 140 \text{ mm}$

Grinding spindle  
 $P = 13 \text{ kW}$   
 $n_2 = 3100 \pm 100 \text{ rpm}$   
 Start up: from idling

### Formulae

#### Drive service factor

$c_2$  from table 4, page 20

#### Design power

$$P_B = P \cdot c_2$$

#### Belt profile selection

from diagram 1, page 21

#### Speed ratio

$$i = \frac{n_1}{n_2} = \frac{d_{w2}}{d_{w1}} = \frac{d_{b2} + 2 h_b}{d_{b1} + 2 h_b}$$

$h_b$  see page 32

#### Effective diameters of ribbed belt pulleys

$d_{b1}$  see page 45

$$d_{b2} = d_{b1} \cdot i + 2 h_b (i - 1)$$

when  $d_{b2}$  is known:

$$d_{b1} = \frac{d_{b2}}{i} + 2 h_b \left( \frac{1}{i} - 1 \right)$$

### Calculation Example

$$c_2 = 1.6$$

$$P_B = 13 \cdot 1.6 = 20.80 \text{ kW}$$

#### Profile PL

$$i = \frac{2440}{3173} = 0.769$$

$d_{b1} = 123 \text{ mm}$  selected

$$d_{b2} = 123 \text{ mm} \cdot 0.769 + 2 \cdot 3.5 (0.769 - 1) = 92.97 \text{ mm}$$

$$d_{b2} = 93 \text{ mm} - \text{see page 44}$$

# DRIVE DESIGN

## FORMULAE AND CALCULATION EXAMPLE



### Formulae

#### Recalculation of speed of driven machine

$$i_{\text{actual}} = \frac{d_{w2}}{d_{w1}} = \frac{d_{b2} + 2 \cdot h_b}{d_{b1} + 2 \cdot h_b}$$

$$n_2 \text{ actual} = \frac{n_1}{i_{\text{actual}}}$$

#### Drive centre distance (suggested)

Recommendation:  $a > 0.7 \quad (d_{bg} + d_{bk})$   
 $a < 2 \quad (d_{bg} + d_{bk})$

#### Effective length of ribbed belt

$$L_{bth} \approx 2a + 1.57(d_{bg} + d_{bk}) + \frac{(d_{bg} - d_{bk})^2}{4a}$$

Actual:

$$L_{bth} = 2a \cdot \sin \frac{\beta}{2} + \frac{\pi}{2}(d_{bg} + d_{bk}) + \frac{\alpha \cdot \pi}{180^\circ}(d_{bg} - d_{bk})$$

#### Drive centre distance

Calculated from  $L_{bSt}$  and  $L_{bth}$

$$(\text{when } L_{bSt} > L_{bth}) a_{\text{nom}} \approx a + \frac{L_{bSt} - L_{bth}}{2}$$

$$(\text{when } L_{bSt} < L_{bth}) a_{\text{nom}} \approx a - \frac{L_{bth} - L_{bSt}}{2}$$

Actual:

$$a_{\text{nom}} = \frac{L_{bSt} - \frac{\pi}{2}(d_{bg} + d_{bk})}{4} + \sqrt{\left[ \frac{L_{bSt} - \frac{\pi}{2}(d_{bg} + d_{bk})}{4} \right]^2 - \frac{(d_{bg} - d_{bk})^2}{8}}$$

#### Minimum allowance x/y above and below drive centre distance $a_{\text{nom}}$

x/y from table 3, page 19

#### Speed

$$v = \frac{d_{wk} \cdot n_k}{19100} = \frac{(d_{bk} + 2 \cdot h_b) \cdot n_k}{19100}$$

### Calculation Example

$$i_{\text{actual}} = \frac{93 + 2 \cdot 3.5}{123 + 2 \cdot 3.5} = 0.769$$

$$n_2 \text{ actual} = \frac{2440}{0.769} = 3173 \text{ rpm}$$

Required:  
 $3100 \pm 100 \text{ rpm}$   
 (Calculated speed meets requirement)

$a = 380 \text{ mm}$  suggested

$$L_{bth} \approx 2 \cdot 380 + 1.57 \cdot (123 + 93) + \frac{(123 - 93)^2}{4 \cdot 380} \approx 1099.7 \text{ mm}$$

Nearest standard length from page 14 selected

$$L_{bSt} = 1075 \text{ mm}$$

$$a_{\text{nom}} \approx 380 - \frac{1099.7 - 1075}{2} \approx 367.65 \text{ mm}$$

$x \geq 20 \text{ mm} / y \geq 25 \text{ mm}$

$$v = \frac{(93 + 2 \cdot 3.5) \cdot 3173}{19100} = 16.61 \text{ m/s}$$

# DRIVE DESIGN

## FORMULAE AND CALCULATION EXAMPLE



### Formulae

#### Arc of contact correction factor and arc of contact

$$\frac{d_{bg} - d_{bk}}{a_{nom}}$$

Approximate  $\beta^\circ$  and  $c_1$  from table 1, page 16

$$\text{Actual: } \cos \frac{\beta}{2} = \frac{d_{bg} - d_{bk}}{2 a_{nom}}$$

#### Belt length correction factor

$c_3$  from table 2, page 17

#### Power rating per rib

$$P_N \text{ for } \begin{cases} d_{bk} = 93 \text{ mm} \\ n_k = 3173 \text{ rpm} \\ i^* = \frac{1}{0.769} = 1.3 \end{cases} \quad \text{Profile PL from table 8, page 29}$$

The condition  $i \geq 1$  applies for selecting the speed ratio power increment.

#### Number of ribs

$$z = \frac{P \cdot c_2}{P_N \cdot c_1 \cdot c_3}$$

#### Minimum static belt tension per rib

$$T \approx \frac{500 \cdot (2.03 - c_1) \cdot P_B}{c_1 \cdot z \cdot v} + k \cdot v^2 \quad \begin{array}{lll} \text{Profile} & k & f [\text{N}] \\ \text{PH} & 0.005 & 3.0 \\ \text{PJ} & 0.009 & 5.0 \\ \text{PK} & 0.020 & 7.5 \\ \text{PL} & 0.036 & 10.0 \\ \text{PM} & 0.123 & 25.0 \end{array}$$

$k$  from table

#### Minimum static shaft loading

$$S_a \approx 2 T \cdot \sin \frac{\beta}{2} \cdot z$$

#### Belt deflection for a given span length

$$E_a \approx \frac{E \cdot L}{100}$$

$E$  from diagram 2, page 49

$$L = a_{nom} \cdot \sin \frac{\beta}{2}$$

For explanation see chapter  
on tensioning on page 48

### Calculation Example

$$\frac{123 - 93}{368} = 0.082$$

$$\left. \begin{array}{l} \beta \approx 175^\circ \\ c_1 = 1.0 \end{array} \right\} \text{linearly interpolated}$$

$$c_3 = \mathbf{0.86}$$

$$P_N = 2.28 + 0.2 = \mathbf{2.48 \text{ kW}}$$

$$z = \frac{13 \cdot 1.6}{2.48 \cdot 1.0 \cdot 0.86} = 9.74$$

Design:  
**1 optibelt RB ribbed belt 10 PL 1075**

$$T \approx \frac{500 \cdot (2.03 - 1.0) \cdot 20.8}{1.0 \cdot 10 \cdot 16.6} + 0.036 \cdot 16.6^2 \approx \mathbf{75 \text{ N}}$$

$$S_a \approx 2 \cdot 75 \cdot 0.9986 \cdot 10 \approx \mathbf{1500 \text{ N}}$$

$$E_a \approx \frac{2.5 \cdot 367.0}{100} \approx \mathbf{9 \text{ mm}}$$

$$E \approx 2.5 \text{ mm}$$

$$L = 367.6 \cdot 0.9986 = 367.0 \text{ mm}$$



To design drive with:

- optibelt RB Ribbed Belt 10 PL 1075 L<sub>b</sub>
- optibelt RBS Ribbed Belt Pulley for Taper Bushes TB 10 PL 123
- optibelt TB Taper Bush 2012 (bore diameter 14-50 mm)
- optibelt RBS Ribbed Belt Pulley for Taper Bushes TB 10 PL 93
- optibelt TB Taper Bushes 1610 (bore diameter 14-42 mm)



### Tolerances/Indications

<b>Prime mover</b>	:	<b>Electric motor</b>
<b>Driven machine</b>		
Design power	PB:	20.80 kW
<b>Driver unit output</b>	P:	<b>13.00 kW</b>
Driver pulley torque	M:	51 Nm
<b>Speed of driver unit</b>	n <sub>1</sub> :	<b>2440 1/min</b>
<b>Effective output speed</b>	n <sub>2</sub> :	<b>3172 1/min</b>
	d <sub>b1</sub> :	<b>123.00 mm</b>
	d <sub>b2</sub> :	<b>93.00 mm</b>
	:	1075 mm
<b>Effective drive centre distance</b>	a:	<b>367.55 mm</b>
Effective speed ratio	i:	0.77
Allowance for installation	y:	25.00 mm
Allowance for tensioning	x:	20.00 mm
<b>Effective drive service factor</b>	c <sub>2</sub> :	<b>1.64</b>
Belt speed	v:	16.61 m/s
Flexing cycles	f <sub>B</sub> :	30.90 1/s
Power rating per belt	P <sub>N</sub> :	2.49 kW
Arc of contact correction factor	c <sub>1</sub> :	1.00
Belt length correction factor	c <sub>3</sub> :	0.86
Arc of contact for small pulley	β:	175.32 °
Pulley face width	b <sub>2</sub> :	48.90 mm
Span length	l:	367.24 mm
<b>Calculated number of belts</b>	z <sub>th</sub> :	<b>9.74</b>
Drive unit weight	:	– kg
Static shaft loading, initial installation	S <sub>ast</sub> :	1941 –
Static shaft loading, used belt	S <sub>ast</sub> :	1493 N
Dynamic shaft loading	S <sub>dyn</sub> :	1308 N

<b>Belt tension methods</b>	<b>Initial installation</b>	<b>Operating voltage</b>	
for predetermined c <sub>2</sub> =	1.60	New belt	Used belt
1. optibelt OPTIKRIK II	Static shaft loading per belt:	971 N	747 N
2. Deflection with tension gauge	Test load:	100 N	100 N
	Deflection:	7.34 mm	8.45 mm
3. Length addition per 1000 mm belt length	:	2.85 mm	2.11 mm
4. optibelt TT 3 / optibelt TT MINI Frequency Tension Gauge	Frequency:	70.72 1/s	62.02 1/s

Concerning liability consult our general terms and conditions.












# SPECIAL DRIVES

## V-FLAT DRIVE




The V-flat drive utilises a ribbed belt pulley and a flat faced pulley. Under certain conditions, this type of drive can be used for drives which are subject to shock loadings or have high moments of inertia. Because flywheels or flat pulleys are quite often already fitted, drive costs can be reduced. When



converting a flat belt drive to a V-Flat drive, it is usually economical to continue to use the large flat pulley.

a	= Drive centre distance	[mm]
b	= Flat pulley face width	[mm]
b <sub>2</sub>	= Ribbed belt pulley face width	[mm]
D <sub>a</sub>	= Flat pulley outside diameter	[mm]
D <sub>Z</sub>	= Allowance for determining the theoretical diameter	[mm]
d <sub>b</sub>	= Effective diameter of ribbed belt pulley	[mm]
f	= Allowance for determining the flat pulley face width	[mm]
h	= Crown height per 100 mm of pulley face width	[mm]
i	= Speed ratio	
L <sub>bth</sub>	= Calculated belt effective length	[mm]



# SPECIAL DRIVES

## V-FLAT DRIVE



### Calculation of V-Flat Drives

The calculation for a V-flat drive is undertaken in the same manner as shown on pages 22 to 24. The following important requirements must be checked so as to ensure a reliable and efficient V-flat drive.

- The small pulley must always be a grooved pulley.
- The V-flat drive is particularly economical when

$$K = \frac{D_a - d_b}{a} \text{ lies between } 0.5 \text{ and } 1.15.$$

The ideal drive is achieved when  $K = 0.85$ . If the "K" factor falls outside the recommended range, it is then more economical to use a normal ribbed belt drive with grooved pulleys.

- The following recommendations are made based upon the above requirements:

Speed ratio	$i = \frac{D_a + D_z}{d_b + 2 h_b} \geq 3$
Drive centre distance	$a_{all} \geq D_a$
	$a = \frac{D_a - d_b}{0.85}$
K factor	$K = \frac{D_a - d_b}{a}$ $K_{all} \text{ 0.5 to 1.15}$

- When calculating the number of ribs and the belt tension, care must be taken to ensure that a **special arc of contact correction factor  $c_1$**  as detailed in the following table 10 is applied.

Table 10: Arc of Contact Correction Factor  $c_1$  (for V-Flat Drives Only)

$K = \frac{D_a - d_b}{a}$	$\beta \approx$	$c_1$
0	180°	0.75
0.07	176°	0.76
0.15	170°	0.77
0.22	167°	0.79
0.29	163°	0.79
0.35	160°	0.80
0.40	156°	0.81
0.45	153°	0.81
0.50	150°	0.82
0.57	146°	0.83
0.64	143°	0.84
0.70	140°	0.85
0.75	137°	0.85
0.80	134°	0.86
0.85	130°	0.86
0.92	125°	0.84
1.00	120°	0.82
1.07	115°	0.80
1.15	110°	0.78
1.21	106°	0.77
1.30	100°	0.73
1.36	96°	0.72
1.45	90°	0.70

The length calculation is for the effective length  $L_b$ . Therefore, in order to obtain the theoretical calculation diameter, an allowance  $D_z$  must be added to the flat pulley outside diameter.

Table 11: Effective Line Difference  $h_b$

Profile	PH	PJ	PK	PL	PM
$h_b$ nominal dimension	0.80	1.25	1.60	3.50	5.00
$D_z$	1.60	2.70	3.50	6.50	11.00

### Calculation of the effective length

$$L_{bh} \approx 2 a + 1.57 (d_b + D_a + D_z) + \frac{(D_a + D_z - d_b)^2}{4 a}$$

### Formula:

#### Calculation of the static belt tension for V-flat drives

$$T = \frac{500 \cdot (2.25 - c_1) \cdot P_B}{c_1 \cdot z \cdot v} + k \cdot v^2$$

In addition to the drive design on pages 22 to 24, the static belt tension for V-flat drives must be calculated with the adjacent formula.

# SPECIAL DRIVES

## TENSION/GUIDE IDLERS



Tensioning/guide pulleys are ribbed or flat faced and do not transmit power within a drive system. Because they create additional bending stresses within the belt their use should be restricted to the following applications if possible:

- with fixed drive centres to produce the required belt tension and to provide for maximum belt stretch and wear
- as damping and guide rollers with long span lengths
- as guide rollers on drives where the pulleys are not all positioned in one plane
- as movable tensioners, to achieve a constant belt tension. This results in reduced maintenance and longer service life. The tension force is normally generated by springs, pneumatics or hydraulics.

If idler pulleys have to be used for the reasons mentioned above, the following criteria should be observed in drive design:

- position of the pulley in the belt span
- diameter
- shape
- the adjustment travel of the pulley, both for tensioning and retensioning the ribbed belts
- correction of the power rating per rib  $P_N$

### Idler Arrangement

Idlers can be used as inside or outside idlers. The end position of the idler must be based on the maximum belt stretch assumption. Flat pulleys, whether used inside or outside should be placed as far away as possible from the next grooved pulley that the ribbed belt will run onto. Misalignment of the idler and the pulley due to lateral movements on the flat pulley can largely be prevented as a result.


If the design conditions do not favour an outside idler, an inside idler is then generally more advantageous. Inside idler diameters can be smaller than outside idler diameters.

**Inside idlers** can be either grooved pulleys or flat pulleys. Inside idlers reduce the arc of contact on the loaded pulleys and hence also the arc of contact correction factor  $c_1$ . When calculating the number of ribs, the arc of contact correction factor is to be selected at the point of the maximum belt extension (see table 14, page 34).

Ribbed belt pulleys are to be preferred as inside idlers on long spans as flat pulleys could permit the development of lateral vibration.

**Outside idlers** must always take the form of flat pulleys as they run on the top surface of the belt. They increase the arc of contact. Care must be taken however to ensure that the maximum possible belt stretch is taken up, and that contact with the opposite span is prevented.

### Inside Idler



The diametrically opposed bending caused when outside idlers are used can lead to a reduction of the belt service life.

### Idlers on the Tight/Slack Side

Both the theoretical power transmission formulae and actual practice have shown that wherever possible the idler should be placed on the slack side of the drive. This allows the idler tension force to be maintained at a considerably lower level. A spring loaded idler must not be used in a reversing drive because the tight and slack sides change continuously. Our engineers will be pleased to advise you about special problems regarding spring loaded idlers!

### Minimum Diameter for Inside Idlers

Inside idler  $\geq$  the smallest driven pulley in the system

### Minimum Diameter for Outside Idlers

Outside idler  $\geq$  1.2 times the smallest loaded pulley in the system

Table 12: Minimum Diameter for Idlers


Profile	Minimum diameter of inside idler [mm]	Minimum diameter of outside idler [mm]
PH	20	40
PJ	25	50
PK	50	70
PL	100	150
PM	200	300

Failure to observe the minimum recommended idler diameter will impair the service life of the ribbed belts.

### Idler Design

Ribbed belt pulleys used as idlers normally have standard groove dimensions. Flat pulleys should wherever possible be cylindrical, not crowned.

### Outside Idler



# SPECIAL DRIVES

## TENSION/GUIDE IDLERS



### Drive Calculation

The length calculation and the determination of the number of ribs is undertaken as for two-pulley drives. Certain details must, however, be taken into account:

1. Calculate the ribbed belt length over two pulleys using the formula:

$$L_{bth} \approx 2 a + 1.57 (d_{bg} + d_{bk}) + \frac{(d_{bg} - d_{bk})^2}{4 a}$$


2. If the ribbed belt has to be fitted with a fixed drive centre distance, twice the allowance **y** should be added to the belt length  $L_{bth}$  (see table 3, page 19).

$$L_b = L_{bth} + 2 y$$

3. The next longest standard length  $L_{bst}$  should then be selected.

A check should be made to determine whether the belt can be adequately tensioned with the idler in the outermost position. In this idler position, both the standard length  $L_{bst}$  as well as double the allowance **x** must be taken up (see table 3, page 19).

$$L_b \text{ for idler end position} = L_{bst} + 2 x$$



### Number of Idlers

The application of idlers increases the bending stress in the ribbed belts. To avoid a reduction in belt service life, the idler correction factor  $c_4$  must also be included in the calculation. This correction factor takes the number of idlers into consideration with the minimum diameter being maintained.

**Table 13**

Number of idlers	$c_4$
0	1.00
1	0.91
2	0.86
3	0.81

The nominal power rating  $P_N$  per rib is as previously based on the smallest **loaded pulley**.

In determining the arc of contact correction factor  $c_1$  the **smallest contact angle of the loaded pulleys** which occurs at maximum belt extension must be used.

**Table 14: Arc of Contact Correction Factor  $c_1$**

$\beta \approx$	$c_1$	$\beta \approx$	$c_1$
75°	0.78	175°	1.00
80°	0.82	180°	1.00
85°	0.84	185°	1.00
90°	0.85	190°	1.01
95°	0.87	195°	1.01
100°	0.89	200°	1.01
105°	0.90	205°	1.01
110°	0.91	210°	1.01
115°	0.92	215°	1.02
120°	0.93	220°	1.02
125°	0.94	225°	1.02
130°	0.95	230°	1.02
135°	0.96	240°	1.02
140°	0.97	250°	1.02
145°	0.97		
150°	0.98		
155°	0.98		
160°	0.99		
165°	0.99		
170°	0.99		


The following formula for determining the number of ribs is obtained using the idler correction factor  $c_4$ :

$$z = \frac{P \cdot c_2}{P_N \cdot c_1 \cdot c_3 \cdot c_4}$$

# RIBBED BELT PULLEYS

## MEASURING PULLEYS – LENGTH MEASURING CONDITIONS

### TO DIN 7867 / ISO 9982



**Table 15**

Profile	Effective circumference $U_b = d_b \cdot \pi$ [mm]	Effective diameter $d_b$	Groove angle $\alpha \pm 0.5^\circ$	Checking rod diameter $d_s \pm 0.01$ [mm]	Diameter over rod $P \pm 0.1$ [mm]	Groove depth $t_{min}$ [mm]	$r_{t min}$ [mm]	Measuring force per rib $Q$ [N]
<b>PH*</b>	100	31.8	40°	1.0	31.94	1.33	0.15	30
<b>PH</b>	300	95.5	40°	1.0	95.60	1.33	0.15	30
<b>PJ*</b>	100	31.8	40°	1.5	32.06	2.06	0.20	50
<b>PJ</b>	300	95.5	40°	1.5	95.72	2.06	0.20	50
<b>PK</b>	300	95.5	40°	2.5	96.48	3.45	0.25	100
<b>PL</b>	500	159.2	40°	3.5	161.51	4.92	0.40	200
<b>PM</b>	800	254.6	40°	7.0	259.17	10.03	0.75	450

\*These values apply only for effective lengths under 457 mm.


The appropriate manufacturing tolerances for the grooves and dimensions of the measuring pulleys are given in tables 15 and 16. Care must be taken to monitor wear or damage. Other diameters may be used for the measuring pulleys providing the groove dimensions from the tables are used.

#### Measuring of Ribbed Belt Length

The belt is placed over two identical measuring pulleys with a groove configuration as shown in the adjoining figure. A load is applied to the moveable pulley until the measuring force  $Q$  is exerted on the ribbed belt. The ribbed belt should be rotated at least three revolutions before measuring the drive centre distance  $a$ . Only then is the belt settled properly into the pulley grooves and exact measurements are possible. The effective length is the result of twice the centre distance  $a$  plus the effective circumference of the measuring pulley.


$$L_b = 2a + U_b$$

#### Method of Measuring Ribbed Belt Effective Length



# RIBBED BELT PULLEYS

## DIMENSIONS TO DIN 7867 / ISO 9982



**Table 16**

Profile	Effective diameter $d_b \text{ min}$ [mm]	Groove angle $\alpha \pm 0.5^\circ$	Groove pitch $e$ [mm]	$\Sigma e \pm 0.3$ [mm]	Groove depth $t_{\min}$ [mm]	$f_{\min}$ [mm]	$h_b$ [mm]	$r_f \text{ min}$ [mm]	$r_b \text{ max}$ [mm]	$2 h_s$ [mm]	$2 \delta_{\max}$ [mm]
<b>PH</b>	13	$40^\circ$	$1.60 (\pm 0.03)$	$(z - 1) 1.60$	1.33	1.3	0.80	0.15	0.30	0.11	0.69
<b>PJ</b>	20	$40^\circ$	$2.34 (\pm 0.03)$	$(z - 1) 2.34$	2.06	1.8	1.25	0.20	0.40	0.23	0.81
<b>PK</b>	45	$40^\circ$	$3.56 (\pm 0.05)$	$(z - 1) 3.56$	3.45	2.5	1.60	0.25	0.50	0.99	1.68
<b>PL</b>	75	$40^\circ$	$4.70 (\pm 0.05)$	$(z - 1) 4.70$	4.92	3.3	3.50	0.40	0.40	2.36	3.50
<b>PM</b>	180	$40^\circ$	$9.40 (\pm 0.08)$	$(z - 1) 9.40$	10.03	6.4	5.00	0.75	0.75	4.53	5.92

The diameter  $d_o$  may be reduced by the dimension  $2 \delta - 2 h_s$  at the manufacturer's discretion.

The arc with radius  $r_f$  must have an angle of at least  $30^\circ$  and merge tangentially with the edge of the groove.

### Pulley Face Width $b_2$

$$b_2 = e(z - 1) + 2f$$

The difference between the diameters, measured as distance  $p$ , between the outer tangential plane of the test pin in all the grooves of a pulley must not exceed the value given in table 17.

### Table 17: Groove to Groove Diameter Variation

Pulley effective diameter [mm]	Tolerance for no. of grooves [mm]		Allowance for each extra groove [mm]
	$\leq 6$ grooves	$\leq 10$ grooves	
$\leq 74$	0.10	—	0.003
$> 74 \leq 500$	—	0.15	0.005
$> 500$	—	0.25	0.010

### Material

All conventional easily machined material may be used, preferably steel, cast iron, aluminium alloy, brass or high strength plastics.

### Surface Finish

Groove surface should have a maximum roughness  $R_z \leq 3.2 \mu\text{m}$  and must be free from surface defects.

### Balancing

For velocities  $< 30 \text{ m/s}$  static balancing is sufficient. Dynamic balancing is necessary for velocities  $\geq 30 \text{ m/s}$ .

### Manufacture

Pulleys for optibelt RB ribbed belts are made to your specification. Cutting tools for ribbed belt pulleys are available on special request.

### Table 18: Run Out Tolerance


Effective diameter $d_b$ [mm]	Run out tolerance $t_R$
$\leq 74$	0.13
$> 74 \leq 250$	0.25
$> 250$	$0.25 + 0.0004$ per mm effective diameter above 250

### Side Wobble Tolerance

The side wobble tolerance  $t_p$  is  $0.002 \text{ mm}$  for each mm effective diameter.

### Pitch Diameter


The schematic illustration shows the seating of a ribbed belt in the pulley.





# RIBBED BELT PULLEYS

## FOR TAPER BUSHES, PROFILE PJ




Designation	No. of grooves	Pulley type	Material	$d_b$ [mm]	$b_2$ [mm]	B [mm]	N [mm]	D [mm]	Taper bush
TB 4 PJ 47.5	4	1	GG	47.5	13	23	23	47.5	1008
TB 4 PJ 52.5	4	1	GG	52.5	13	23	23	47.5	1008
TB 4 PJ 57.5	4	1	GG	57.5	13	23	23	54.0	1108
TB 4 PJ 62.5	4	1	GG	62.5	13	23	23	54.0	1108
TB 4 PJ 67.5	4	1	GG	67.5	13	23	23	54.0	1108
TB 4 PJ 72.5	4	1	GG	72.5	13	23	23	54.0	1108
TB 4 PJ 77.5	4	1	GG	77.5	13	26	26	70.0	1210
TB 4 PJ 82.5	4	1	GG	82.5	13	26	26	78.0	1210
TB 4 PJ 87.5	4	1	GG	87.5	13	26	26	78.0	1210
TB 4 PJ 92.5	4	1	GG	92.5	13	26	26	78.0	1210
TB 4 PJ 97.5	4	1	GG	97.5	13	26	26	78.0	1210
TB 4 PJ 102.5	4	1	GG	102.5	13	26	26	85.0	1610
TB 4 PJ 107.5	4	1	GG	107.5	13	26	26	85.0	1610
TB 4 PJ 112.5	4	1	GG	112.5	13	26	26	85.0	1610
TB 4 PJ 117.5	4	1	GG	117.5	13	26	26	85.0	1610
TB 4 PJ 122.5	4	1	GG	122.5	13	26	26	85.0	1610
TB 4 PJ 127.5	4	1	GG	127.5	13	26	26	85.0	1610
TB 4 PJ 137.5	4	1	GG	137.5	13	26	26	85.0	1610
TB 4 PJ 152.5	4	1	GG	152.5	13	26	26	85.0	1610
TB 4 PJ 162.5	4	1	GG	162.5	13	26	26	85.0	1610
TB 4 PJ 172.5	4	1	GG	172.5	13	26	26	85.0	1610
TB 4 PJ 182.5	4	1	GG	182.5	13	26	26	85.0	1610
TB 4 PJ 192.5	4	1	GG	192.5	13	26	26	85.0	1610
TB 4 PJ 202.5	4	1	GG	202.5	13	33	33	100.0	2012
TB 4 PJ 222.5	4	1	GG	222.5	13	33	33	100.0	2012


Taper bush	1008	1108	1210	1610	2012
Bore $d_2$ [mm] from ... to ...	10-25	10-28	11-32	14-42	14-50

GG= Cast iron  
Further sizes upon request.  
We reserve to alter specifications without notice.  
Bore diameters  $d_2$  see page 37.

# RIBBED BELT PULLEYS FOR TAPER BUSHES, PROFILE PJ



Type 1



Type 4

Designation	No. of grooves	Pulley type	Material	$d_b$ [mm]	$b_2$ [mm]	B [mm]	N [mm]	D [mm]	Taper bush
TB 8 PJ 47.5	8	4	GG	47.5	23	23	23	—	1008
TB 8 PJ 52.5	8	4	GG	52.5	23	23	23	—	1008
TB 8 PJ 57.5	8	4	GG	57.5	23	23	23	—	1108
TB 8 PJ 62.5	8	4	GG	62.5	23	23	23	—	1108
TB 8 PJ 67.5	8	4	GG	67.5	23	23	23	—	1108
TB 8 PJ 72.5	8	4	GG	72.5	23	23	23	—	1108
TB 8 PJ 77.5	8	1	GG	77.5	23	26	26	70.0	1210
TB 8 PJ 82.5	8	1	GG	82.5	23	26	26	78.0	1210
TB 8 PJ 87.5	8	1	GG	87.5	23	26	26	78.0	1210
TB 8 PJ 92.5	8	1	GG	92.5	23	26	26	78.0	1210
TB 8 PJ 97.5	8	1	GG	97.5	23	26	26	78.0	1210
TB 8 PJ 102.5	8	1	GG	102.5	23	26	26	85.0	1610
TB 8 PJ 107.5	8	1	GG	107.5	23	26	26	85.0	1610
TB 8 PJ 112.5	8	1	GG	112.5	23	26	26	85.0	1610
TB 8 PJ 117.5	8	1	GG	117.5	23	26	26	85.0	1610
TB 8 PJ 122.5	8	1	GG	122.5	23	26	26	85.0	1610
TB 8 PJ 127.5	8	1	GG	127.5	23	26	26	85.0	1610
TB 8 PJ 137.5	8	1	GG	137.5	23	26	26	85.0	1610
TB 8 PJ 152.5	8	1	GG	152.5	23	26	26	85.0	1610
TB 8 PJ 162.5	8	1	GG	162.5	23	26	26	85.0	1610
TB 8 PJ 172.5	8	1	GG	172.5	23	26	26	85.0	1610
TB 8 PJ 182.5	8	1	GG	182.5	23	26	26	85.0	1610
TB 8 PJ 192.5	8	1	GG	192.5	23	26	26	85.0	1610
TB 8 PJ 202.5	8	1	GG	202.5	23	33	33	100.0	2012
TB 8 PJ 222.5	8	1	GG	222.5	23	33	33	100.0	2012

Taper bush	1008	1108	1210	1610	2012
Bore $d_2$ [mm] from ... to ...	10-25	10-28	11-32	14-42	14-50


GG = Cast iron

Further sizes upon request.

We reserve to alter specifications without notice.

Bore diameters  $d_2$  see page 37.

# RIBBED BELT PULLEYS FOR TAPER BUSHES, PROFILE PJ





Designation	No. of grooves	Pulley type	Material	$d_b$ [mm]	$b_2$ [mm]	B [mm]	N [mm]	D [mm]	Taper bush
TB 12 PJ 62.5	12	2	GG	62.5	32	32	23	50.0	1108
TB 12 PJ 67.5	12	2	GG	67.5	32	32	23	50.0	1108
TB 12 PJ 72.5	12	2	GG	72.5	32	32	23	50.0	1108
TB 12 PJ 77.5	12	2	GG	77.5	32	32	26	62.0	1210
TB 12 PJ 82.5	12	2	GG	82.5	32	32	26	62.0	1210
TB 12 PJ 87.5	12	2	GG	87.5	32	32	26	70.0	1610
TB 12 PJ 92.5	12	2	GG	92.5	32	32	26	70.0	1610
TB 12 PJ 97.5	12	2	GG	97.5	32	32	26	70.0	1610
TB 12 PJ 102.5	12	2	GG	102.5	32	32	26	70.0	1610
TB 12 PJ 107.5	12	2	GG	107.5	32	32	26	70.0	1610
TB 12 PJ 112.5	12	2	GG	112.5	32	32	26	70.0	1610
TB 12 PJ 117.5	12	2	GG	117.5	32	32	26	70.0	1610
TB 12 PJ 122.5	12	2	GG	122.5	32	32	26	70.0	1610
TB 12 PJ 127.5	12	1	GG	127.5	32	32	33	100.0	2012
TB 12 PJ 137.5	12	1	GG	137.5	32	32	33	100.0	2012
TB 12 PJ 152.5	12	1	GG	152.5	32	32	33	100.0	2012
TB 12 PJ 162.5	12	1	GG	162.5	32	32	33	100.0	2012
TB 12 PJ 172.5	12	1	GG	172.5	32	32	33	100.0	2012
TB 12 PJ 182.5	12	1	GG	182.5	32	46	46	110.0	2517
TB 12 PJ 192.5	12	1	GG	192.5	32	46	46	110.0	2517
TB 12 PJ 202.5	12	1	GG	202.5	32	46	46	110.0	2517
TB 12 PJ 222.5	12	1	GG	222.5	32	46	46	110.0	2517

Taper bush	1108	1210	1610	2012	2517
Bore $d_2$ [mm] from ... to ...	10-28	11-32	14-42	14-50	16-60

GG = Cast iron  
Further sizes upon request.  
We reserve to alter specifications without notice.  
Bore diameters  $d_2$  see page 37.

# RIBBED BELT PULLEYS FOR TAPER BUSHES, PROFILE PJ



Designation	No. of grooves	Pulley type	Material	$d_b$ [mm]	$b_2$ [mm]	B [mm]	N [mm]	D [mm]	Taper bush
TB 16 PJ 62.5	16	2	GG	62.5	41	41	23	50.0	1108
TB 16 PJ 67.5	16	2	GG	67.5	41	41	23	50.0	1108
TB 16 PJ 72.5	16	2	GG	72.5	41	41	26	62.0	1210
TB 16 PJ 77.5	16	2	GG	77.5	41	41	26	62.0	1210
TB 16 PJ 82.5	16	2	GG	82.5	41	41	26	62.0	1210
TB 16 PJ 87.5	16	2	GG	87.5	41	41	26	70.0	1610
TB 16 PJ 92.5	16	2	GG	92.5	41	41	26	70.0	1610
TB 16 PJ 97.5	16	2	GG	97.5	41	41	26	70.0	1610
TB 16 PJ 102.5	16	2	GG	102.5	41	41	26	70.0	1610
TB 16 PJ 107.5	16	2	GG	107.5	41	41	26	70.0	1610
TB 16 PJ 112.5	16	2	GG	112.5	41	41	33	85.0	2012
TB 16 PJ 117.5	16	2	GG	117.5	41	41	33	85.0	2012
TB 16 PJ 122.5	16	2	GG	122.5	41	41	33	85.0	2012
TB 16 PJ 127.5	16	2	GG	127.5	41	41	33	85.0	2012
TB 16 PJ 137.5	16	2	GG	137.5	41	41	33	85.0	2012
TB 16 PJ 152.5	16	2	GG	152.5	41	41	33	85.0	2012
TB 16 PJ 162.5	16	2	GG	162.5	41	41	33	85.0	2012
TB 16 PJ 172.5	16	2	GG	172.5	41	41	33	85.0	2012
TB 16 PJ 182.5	16	1	GG	182.5	41	46	46	110.0	2517
TB 16 PJ 192.5	16	1	GG	192.5	41	46	46	110.0	2517
TB 16 PJ 202.5	16	1	GG	202.5	41	46	46	110.0	2517
TB 16 PJ 222.5	16	1	GG	222.5	41	46	46	110.0	2517

Taper bush	1108	1210	1610	2012	2517
Bore $d_2$ [mm] from ... to ...	10-28	11-32	14-42	14-50	16-60


GG = Cast iron

Further sizes upon request.

We reserve to alter specifications without notice.

Bore diameters  $d_2$  see page 37.

# RIBBED BELT PULLEYS FOR TAPER BUSHES, PROFILE PL



Designation	No. of grooves	Pulley type	Material	$d_b$ [mm]	$b_2$ [mm]	B [mm]	N [mm]	D [mm]	Taper bush
TB 6 PL 78	6	2	GG	78	33	33	26	62.0	1210
TB 6 PL 83	6	2	GG	83	33	33	26	62.0	1210
TB 6 PL 88	6	2	GG	88	33	33	26	70.0	1610
TB 6 PL 93	6	2	GG	93	33	33	26	70.0	1610
TB 6 PL 98	6	2	GG	98	33	33	26	70.0	1610
TB 6 PL 103	6	2	GG	103	33	33	26	70.0	1610
TB 6 PL 108	6	2	GG	108	33	33	26	70.0	1610
TB 6 PL 113	6	2	GG	113	33	33	26	70.0	1610
TB 6 PL 118	6	2	GG	118	33	33	26	70.0	1610
TB 6 PL 123	6	4	GG	123	33	33	33	—	2012
TB 6 PL 133	6	4	GG	133	33	33	33	—	2012
TB 6 PL 148	6	4	GG	148	33	33	33	—	2012
TB 6 PL 158	6	4	GG	158	33	33	33	—	2012
TB 6 PL 168	6	4	GG	168	33	33	33	—	2012
TB 6 PL 178	6	1	GG	178	33	46	46	110.0	2517
TB 6 PL 188	6	1	GG	188	33	46	46	110.0	2517
TB 6 PL 198	6	1	GG	198	33	46	46	110.0	2517
TB 6 PL 218	6	1	GG	218	33	46	46	110.0	2517
TB 6 PL 238	6	1	GG	238	33	46	46	110.0	2517
TB 6 PL 258	6	1	GG	258	33	46	46	110.0	2517
TB 6 PL 278	6	1	GG	278	33	46	46	110.0	2517
TB 6 PL 298	6	1	GG	298	33	46	46	110.0	2517
TB 6 PL 318	6	1	GG	318	33	46	46	110.0	2517
TB 6 PL 348	6	1	GG	348	33	46	46	110.0	2517
TB 6 PL 388	6	1	GG	388	33	46	46	110.0	2517

Taper bush	1210	1610	2012	2517
Bore $d_2$ [mm] from ... to ...	11-32	14-42	14-50	16-60

GG = Cast iron



Further sizes upon request.

We reserve to alter specifications without notice.

Bore diameters  $d_2$  see page 37.

# RIBBED BELT PULLEYS

## FOR TAPER BUSHES, PROFILE PL



Designation	No. of grooves	Pulley type	Material	$d_b$ [mm]	$b_2$ [mm]	B [mm]	N [mm]	D [mm]	Taper bush
TB 8 PL 78	8	2	GG	78	42	42	26	62.0	1210
TB 8 PL 83	8	2	GG	83	42	42	26	62.0	1210
TB 8 PL 88	8	2	GG	88	42	42	26	70.0	1610
TB 8 PL 93	8	2	GG	93	42	42	26	70.0	1610
TB 8 PL 98	8	2	GG	98	42	42	26	70.0	1610
TB 8 PL 103	8	2	GG	103	42	42	33	85.0	2012
TB 8 PL 108	8	2	GG	108	42	42	33	85.0	2012
TB 8 PL 113	8	2	GG	113	42	42	33	85.0	2012
TB 8 PL 118	8	2	GG	118	42	42	33	85.0	2012
TB 8 PL 123	8	2	GG	123	42	42	33	85.0	2012
TB 8 PL 133	8	2	GG	133	42	42	33	85.0	2012
TB 8 PL 148	8	2	GG	148	42	42	33	85.0	2012
TB 8 PL 158	8	2	GG	158	42	42	33	85.0	2012
TB 8 PL 168	8	2	GG	168	42	42	33	85.0	2012
TB 8 PL 178	8	1	GG	178	42	46	46	110.0	2517
TB 8 PL 188	8	1	GG	188	42	46	46	110.0	2517
TB 8 PL 198	8	1	GG	198	42	46	46	110.0	2517
TB 8 PL 218	8	1	GG	218	42	46	46	110.0	2517
TB 8 PL 238	8	1	GG	238	42	46	46	110.0	2517
TB 8 PL 258	8	1	GG	258	42	46	46	110.0	2517
TB 8 PL 278	8	1	GG	278	42	46	46	110.0	2517
TB 8 PL 298	8	1	GG	298	42	46	46	110.0	2517
TB 8 PL 318	8	1	GG	318	42	46	46	110.0	2517
TB 8 PL 348	8	1	GG	348	42	46	46	110.0	2517
TB 8 PL 388	8	1	GG	388	42	46	46	110.0	2517

Taper bush	1210	1610	2012	2517
Bore $d_2$ [mm] from ... to ...	11-32	14-42	14-50	16-60

GG = Cast iron



Further sizes upon request.

We reserve to alter specifications without notice.

Bore diameters  $d_2$  see page 37.

# RIBBED BELT PULLEYS

## FOR TAPER BUSHES, PROFILE PL





Designation	No. of grooves	Pulley type	Material	$d_b$ [mm]	$b_2$ [mm]	B [mm]	N [mm]	D [mm]	Taper bush
TB 10 PL 88	10	3	GG	88	53	53	26	70.0	1610
TB 10 PL 93	10	3	GG	93	53	53	26	70.0	1610
TB 10 PL 98	10	3	GG	98	53	53	26	70.0	1610
TB 10 PL 103	10	2	GG	103	53	53	33	85.0	2012
TB 10 PL 108	10	2	GG	108	53	53	33	85.0	2012
TB 10 PL 113	10	2	GG	113	53	53	33	85.0	2012
TB 10 PL 118	10	2	GG	118	53	53	33	85.0	2012
TB 10 PL 123	10	2	GG	123	53	53	33	85.0	2012
TB 10 PL 133	10	2	GG	133	53	53	33	85.0	2012
TB 10 PL 148	10	2	GG	148	53	53	33	85.0	2012
TB 10 PL 158	10	2	GG	158	53	53	33	85.0	2012
TB 10 PL 168	10	2	GG	168	53	53	33	85.0	2012
TB 10 PL 178	10	2	GG	178	53	53	46	105.0	2517
TB 10 PL 188	10	2	GG	188	53	53	46	105.0	2517
TB 10 PL 198	10	2	GG	198	53	53	46	105.0	2517
TB 10 PL 218	10	2	GG	218	53	53	46	105.0	2517
TB 10 PL 238	10	2	GG	238	53	53	46	105.0	2517
TB 10 PL 258	10	2	GG	258	53	53	46	105.0	2517
TB 10 PL 278	10	2	GG	278	53	53	46	105.0	2517
TB 10 PL 298	10	2	GG	298	53	53	46	105.0	2517
TB 10 PL 318	10	2	GG	318	53	53	46	105.0	2517
TB 10 PL 348	10	2	GG	348	53	53	46	105.0	2517
TB 10 PL 388	10	2	GG	388	53	53	46	105.0	2517

Taper bush	1610	2012	2517
Bore $d_2$ [mm] from ... to ...	14-42	14-50	16-60

GG = Cast iron  
 Further sizes upon request.  
 We reserve to alter specifications without notice.  
 Bore diameters  $d_2$  see page 37.

# RIBBED BELT PULLEYS FOR TAPER BUSHES, PROFILE PL



Designation	No. of grooves	Pulley type	Material	$d_b$ [mm]	$b_2$ [mm]	B [mm]	N [mm]	D [mm]	Taper bush
TB 12 PL 88	12	3	GG	88	62	62	26	70.0	1610
TB 12 PL 93	12	3	GG	93	62	62	26	70.0	1610
TB 12 PL 98	12	3	GG	98	62	62	26	70.0	1610
TB 12 PL 103	12	3	GG	103	62	62	33	85.0	2012
TB 12 PL 108	12	3	GG	108	62	62	33	85.0	2012
TB 12 PL 113	12	3	GG	113	62	62	33	85.0	2012
TB 12 PL 118	12	3	GG	118	62	62	33	85.0	2012
TB 12 PL 123	12	3	GG	123	62	62	33	85.0	2012
TB 12 PL 133	12	3	GG	133	62	62	33	85.0	2012
TB 12 PL 148	12	2	GG	148	62	62	46	105.0	2517
TB 12 PL 158	12	2	GG	158	62	62	46	105.0	2517
TB 12 PL 168	12	2	GG	168	62	62	46	105.0	2517
TB 12 PL 178	12	2	GG	178	62	62	46	105.0	2517
TB 12 PL 188	12	2	GG	188	62	62	46	105.0	2517
TB 12 PL 198	12	2	GG	198	62	62	46	105.0	2517
TB 12 PL 218	12	2	GG	218	62	62	46	105.0	2517
TB 12 PL 238	12	2	GG	238	62	62	52	130.0	3020
TB 12 PL 258	12	2	GG	258	62	62	52	130.0	3020
TB 12 PL 278	12	2	GG	278	62	62	52	130.0	3020
TB 12 PL 298	12	2	GG	298	62	62	52	130.0	3020
TB 12 PL 318	12	2	GG	318	62	62	52	130.0	3020
TB 12 PL 348	12	2	GG	348	62	62	52	130.0	3020
TB 12 PL 388	12	2	GG	388	62	62	52	130.0	3020

Taper bush	1610	2012	2557	3020
Bore $d_2$ [mm] from ... to ...	14-42	14-50	16-60	25-75

GG = Cast iron


Further sizes upon request.

We reserve to alter specifications without notice.

Bore diameter  $d_2$  see page 37.

# RIBBED BELT PULLEYS

## FOR TAPER BUSHES, PROFILE PL



Designation	No. of grooves	Pulley type	Material	$d_b$ [mm]	$b_2$ [mm]	B [mm]	N [mm]	D [mm]	Taper bush
TB 16 PL 103	16	3	GG	103	80	80	33	85.0	2012
TB 16 PL 108	16	3	GG	108	80	80	33	85.0	2012
TB 16 PL 113	16	3	GG	113	80	80	33	85.0	2012
TB 16 PL 118	16	3	GG	118	80	80	33	85.0	2012
TB 16 PL 123	16	3	GG	123	80	80	33	85.0	2012
TB 16 PL 133	16	3	GG	133	80	80	33	85.0	2012
TB 16 PL 148	16	3	GG	148	80	80	46	105.0	2517
TB 16 PL 158	16	3	GG	158	80	80	46	105.0	2517
TB 16 PL 168	16	3	GG	168	80	80	46	105.0	2517
TB 16 PL 178	16	3	GG	178	80	80	46	105.0	2517
TB 16 PL 188	16	3	GG	188	80	80	46	105.0	2517
TB 16 PL 198	16	3	GG	198	80	80	46	105.0	2517
TB 16 PL 218	16	3	GG	218	80	80	46	105.0	2517
TB 16 PL 238	16	3	GG	238	80	80	52	130.0	3020
TB 16 PL 258	16	3	GG	258	80	80	52	130.0	3020
TB 16 PL 278	16	3	GG	278	80	80	52	130.0	3020
TB 16 PL 298	16	3	GG	298	80	80	52	130.0	3020
TB 16 PL 318	16	3	GG	318	80	80	52	130.0	3020
TB 16 PL 348	16	3	GG	348	80	80	52	130.0	3020
TB 16 PL 388	16	3	GG	388	80	80	52	130.0	3020

Taper bush	2012	2557	3020
Bore $d_2$ [mm] from ... to ...	14-50	16-60	25-75

GG = Cast iron


Further sizes upon request.

We reserve to alter specifications without notice.

Bore diameters  $d_2$  see page 37.

# RIBBED BELT PULLEYS

## FOR CYLINDRICAL BORE, PROFILE PJ



Type VB (for cylindrical bore)

Designation	No. of grooves	Pulley type	Material	$d_b$ [mm]	$b_1$ [mm]	B [mm]	D [mm]	Pilot bore $d$ [mm]	Finished bore $d_{max}$ [mm]	Weight [≈ kg]
4 PJ 22.5	4	VB	GG	22.5	13	20	25	8	12.0	0.045
4 PJ 27.5	4	VB	GG	27.5	13	20	30	8	14.0	0.070
4 PJ 32.5	4	VB	GG	32.5	13	20	35	8	18.0	0.100
4 PJ 37.5	4	VB	GG	37.5	13	20	40	8	20.0	0.135
4 PJ 42.5	4	VB	GG	42.5	13	20	45	8	22.0	0.180
8 PJ 22.5	8	VB	GG	22.5	23	30	25	8	12.0	0.063
8 PJ 27.5	8	VB	GG	27.5	23	30	30	8	14.0	0.100
8 PJ 32.5	8	VB	GG	32.5	23	30	35	8	18.0	0.150
8 PJ 37.5	8	VB	GG	37.5	23	30	40	8	20.0	0.200
8 PJ 42.5	8	VB	GG	42.5	23	30	45	8	22.0	0.265
12 PJ 22.5	12	VB	GG	22.5	32	40	25	8	12.0	0.086
12 PJ 27.5	12	VB	GG	27.5	32	40	30	8	14.0	0.140
12 PJ 32.5	12	VB	GG	32.5	32	40	35	8	18.0	0.200
12 PJ 37.5	12	VB	GG	37.5	32	40	40	8	20.0	0.280
12 PJ 42.5	12	VB	GG	42.5	32	40	45	8	22.0	0.360

GG = Cast iron

Further sizes upon request.

We reserve to alter specifications without notice.

# DESIGN HINTS

## RIBBED BELT TENSION



The correct level of belt tension is of great importance for trouble free transmission of power, and for the achievement of an acceptable belt service life. Often, tension which is either too high or too low results in early belt failure. A belt which is over tensioned sometimes causes bearing failure in the driver or driven unit.

It has been shown that the more common tensioning instructions – e. g. using the "thumb pressure deflection method" – do not result in tension being obtained which would enable drives to be operated at optimum efficiency. It is therefore recommended that the required static belt tension "T" be calculated individually for every drive using the following Optibelt formulae. The best initial tension is the absolute minimum for a drive which permits the highest level of power transmission under consideration of the normal slip.

Once the ribbed belt has been fitted and the calculated shaft load applied, the tension should be checked, using our Optibelt tension gauge.

The belt should be observed regularly during the first few hours of service. Experience indicates that the first retensioning should be undertaken after running at full load for 0.5 to 4 hours to take up the initial belt stretch.

After approximately 24 hours' running, especially if the belt has not run continuously under full load conditions, the drive should be checked and, if necessary, retensioned. After this, maintenance intervals for the drive can then be increased considerably. In addition, our installation and maintenance instructions should be observed.

Over- or undertensioning of the drive will be avoided if the belt tension is calculated, set and checked by one of the following methods:

### I. Checking the Belt Tension by Span Deflection

This method provides an indirect measurement of the calculated or actual static belt tension.

$E$  = Belt deflection per 100 mm span length [mm]

$E_a$  = Belt deflection for a given span length [mm]

$f$  = Load used to set belt tension per rib [N]

$k$  = Constant for calculation of centrifugal force

$L$  = Span length [mm]

$S_a$  = Minimum static shaft loading [N]

$T$  = Minimum static belt tension per rib [N]

1. Calculate the static belt tension using the following formula:

$$T \approx \frac{500 \cdot (2.03 - c_1) \cdot P_B}{c_1 \cdot z \cdot v^2} + k \cdot v^2$$

The drive should initially be tensioned to a maximum of 1.3 T (initial tensioning).

2. Determine  $E$  – the deflection per 100 mm length – from the belt tension characteristics as given in diagram 2, page 49.


3. Calculate  $E_a$  – the deflection for a given span length – for the actual drive span length  $L$ :

$$E_a \approx \frac{E \cdot L}{100}$$

$$L = a_{\text{nom}} \cdot \sin \frac{\beta}{2}$$

Apply load  $f^*$  using the value from Diagram 2 at right angles to the span at its centre point, as shown in the figure below. Measure the deflection and adjust if necessary until the correct belt tension is achieved.

\* When choosing the load to set belt tension  $f$ , the number of ribs must be taken into consideration.





# DESIGN HINTS

## RIBBED BELT TENSION



**Diagram 2: Ribbed Belt Tension Graphs**



# DESIGN HINTS

## RIBBED BELT TENSION



### II. Checking the Ribbed Belt Tension with a "Length Addition Value"

It has become evident that span deflection methods are not always the ideal checking procedures for ribbed belts. The following very easy method for determining the belt tension is therefore recommended:

1. Calculate the static belt tension "T".

$$T \approx \frac{500 \cdot (2.03 - c_1) \cdot P_B}{c_1 \cdot z \cdot v^2} + k \cdot v^2$$

2. The outside length  $L_a$  of the ribbed belt should be measured on the top surface with the belt slack prior to fitting it to the drive. Measurement may also be carried out on the drive itself, but **without tension**.

3. Calculate the length addition value "A" by using the formula:

$$A \approx L_{bSI} \cdot R$$

$R$  = Stretch factor from table 19, page 51

4. This length addition value "A" should then be added to the measured outside length (from step 2).

$$L_{a*} \approx L_a + A$$

5. The ribbed belt should then be tensioned until the outside length  $L_{a*}$  calculated in step 4 is obtained. The belt tension will then be correct.

6. If the drive is to be retensioned, the ribbed belt must first be slackened off so that it can be measured in a stress free condition. The procedure as detailed in steps 4 and 5 is then repeated.

Tighten the belt until the length measured around the outside is 1103 mm. The belt is then correctly tensioned.

Example:

$$P_B = 23.4 \text{ kW}$$

$$c_1 = 1.0$$

$$v = 16.6 \text{ m/s}$$

Drive specification with 1 optibelt RB ribbed belt  
12 PL 1075

$$T \approx \frac{500 \cdot (2.03 - 1.0) \cdot 23.4}{1.0 \cdot 12 \cdot 16.6} + 0.036 \cdot 16.6^2 \approx 70 \text{ N}$$

**When fitted for the first time, the tension should be multiplied by a factor of 1.3.**

$$T \approx 1.3 \cdot 70 \approx 91 \text{ N}$$

Length measured on the back of the belt whilst slack  
 $L_a = 1100 \text{ mm}$

$$A \approx 1075 \cdot 0.00264 \approx 3 \text{ mm}$$

$$L_{a*} \approx 1100 + 3 = 1103 \text{ mm}$$

### III. Checking the Ribbed Belt Tension by Measurement of the Static Shaft Loading

A very accurate method for the setting of the correct belt tension is by direct measurement of the static shaft loading using the formula:

$$S_a \approx 2 T \cdot \sin \frac{\beta}{2} \cdot z$$

This checking method does, however, call for specialised measuring instruments.

# DESIGN HINTS

## RIBBED BELT TENSION



**Table 19: Stretch Factor R for optibelt RB Ribbed Belts**

Profile	PH	PJ	PK	PL	PM
15	0.00155	0.00090			
20	0.00207	0.00130			
25	0.00263	0.00168			
30	0.00331	0.00206	0.00065	0.00066	
35	0.00407	0.00248	0.00077	0.00080	
40	0.00500	0.00300	0.00093	0.00094	
45	0.00600	0.00348	0.00114	0.00109	
50	0.00700	0.00406	0.00136	0.00127	
55	0.00831	0.00459	0.00160	0.00142	0.00062
60	0.00958	0.00522	0.00192	0.00160	0.00072
65	0.01085	0.00580	0.00223	0.00175	0.00079
70	0.01229	0.00644	0.00254	0.00191	0.00087
75	0.01356	0.00715	0.00280	0.00212	0.00098
80	0.01500	0.00786	0.00312	0.00228	0.00101
85	0.01636	0.00863	0.00346	0.00242	0.00111
90	0.01780	0.00949	0.00377	0.00261	0.00120
95	0.01924	0.01021	0.00411	0.00277	0.00124
100	0.02070	0.01106	0.00445	0.00297	0.00135
120	0.02644	0.01469	0.00572	0.00369	0.00159
140		0.01849	0.00693	0.00437	0.00190
160		0.02229	0.00820	0.00509	0.00219
180			0.00949	0.00580	0.00249
200			0.01095	0.00651	0.00279
220				0.00735	0.00314
240				0.00811	0.00340
250				0.00849	0.00356
260					0.00373
280					0.00405
300					0.00438
350					0.00518
400					0.00598
440					0.00674
460					0.00706
480					0.00742
500					0.00772
520					0.00814
540					0.00850
560					0.00889
580					0.00929
600					0.00968
620					0.01004
640					0.01036
660					0.01076
680					0.01116
700					0.01156
720					0.01196

Intermediate values can be calculated by linear interpolation.

# DESIGN SUPPORT

## TECHNICAL TOOLS

### FREQUENCY METER / TENSION TESTER optibelt TT



The optibelt TT frequency tension tester is an appliance that is used to check the tension of drive belts by means of measuring frequency. Thanks to a compact design, this product offers universal application possibilities in machine construction, in the automotive industry and many other technical applications.

The optibelt TT can even be effortlessly used in difficult-to-reach places so that the tension values of V-belts, ribbed belts and timing belts can be easily and quickly checked.

After start up, the device is immediately ready for obtaining data. The measuring head is held over the belt to be tested (two red LED light points help to position it). The belt is made to vibrate by striking it with a finger or an object. The optibelt TT begins recording data and displays the result in Hertz [Hz]. The condition, colour and type of the belt have no effect upon the measurement.

The tension recommendations can be taken from the Optibelt specifications and the CAP calculation.

$$f = \sqrt{\frac{F_T \cdot 10^6}{4 \cdot m_k \cdot L^2}} \quad [\text{Hz}]$$

with  $F_T$  [N],  $m_k$  [kg/m] or [g/m] and  $L$  [mm]

$$f = \sqrt{\frac{504 \text{ N} \cdot 10^6}{4 \cdot 0.325 \frac{\text{kg}}{\text{m}} \cdot 401^2 \text{ mm}^2}} = 49.1 \text{ Hz}$$

#### Advantages of optibelt TT

- Two trouble-free measuring methods:  
EM: electro magnetic wave  
AC: acceleration, integrated
- Usable also for long centre distances by all-time wide frequency range:  
AC: 1 - 10 Hz  
EM: 6 - 600 Hz
- Easy handling of the measuring head: two red LED points on the belt help to find the correct position
- For hard accessible belt span: measuring head on flexible goose-neck (EM) or with 250 mm cable (AC)
- Safe meter-reading by big display: width 43 mm and height 58 mm, illuminated and colored
- Long running time and environment-friendly by high capacity, rechargeable battery (USB) and changeability
- Chargeable via USB
- No interference in loud and bright environments
- Automatic switch-off function

$T \triangleq$  belt tension [N]

$k \triangleq$  meter weight [kg/m]

$L \triangleq$  belt length [mm]

$f \triangleq$  frequency [Hz]

#### The optibelt TT:

A guarantee for longer durability of your V-belts, ribbed belts, and timing belts!

## DESIGN SUPPORT

### TECHNICAL TOOLS

#### FREQUENCY METER / TENSION TESTER optibelt TT LINE



#### Advantages of optibelt TT DATA

- Comfortable input and selection of belt drive data on touch screen; show own company logo on start display
- Use own belt drive data and general belt set values from optibelt TT database and span length calculation
- Simultaneous display: set, measuring values; simple decision to okay / not okay; select and register tolerances
- Save measurement results and new belt drive data in optibelt TT DATA: Micro SD slot including Micro SD card
- PC synchronisation for database administration with optibelt TT DATA software: USB cable, Micro SD card; optibelt TT DATA update
- Use data from CAP 7.0 in optibelt TT DATA: Send belt drive identification and set values to TT DATA software

#### Advantages of optibelt TT RFID

- Integrated optibelt TT RFID Reader loads belt drive data directly from the machine: RFID LABEL with data set
- RFID database administration on optibelt TT RFID or, more comfortable on PC: optibelt TT DATA/RFID software
- RFID LABEL data in- and output with optibelt TT RFID or with PC: optional USB RFID Reader Dongle
- RFID LABEL with free print area for address data of machine and user; adhesive backside, on paper rolls
- Print and data input of RFID LABEL with RFID printer: Data e-mailing, RFID LABEL by post
- Easy mounting of RFID LABEL on the machine: 6 mm thick, adhesive and screwable RFID PLATE

# Follow soon!

# DESIGN HINTS

## DETERMINING THE STATIC SHAFT LOADING / SHAFT LOADING UNDER DYNAMIC CONDITIONS



In order to prevent premature bearing failure, shaft fracture or over engineered bearings and shafts, it is recommended that the dynamic axial force be calculated exactly. This is the only way to determine the stresses to which these components are exposed in the prime mover and driven machines.

In the case of two pulley drives, the driver and driven shafts or bearings are subject to the same dynamic axial force, but in opposite directions.

When tension or guide pulleys are incorporated, the magnitude and direction of the axial force are almost always different on each pulley. If the magnitude and direction of the dynamic axial force is to be determined, a graphical solution using the force parallelogram for the dynamic forces in the tight side  $S_1$  and slack side  $S_2$  is recommended. If only the magnitude of the dynamic axial force is to be determined, this can be achieved using the formula " $S_{a\ dyn}$ ". Both methods are illustrated by the following example.

Details of the calculation example given on pages 22 to 24:

$$P_B = 23.4 \text{ kW} \quad c_1 = 1.0 \\ v = 16.6 \text{ m/s} \quad \beta = 175^\circ$$

### Dynamic tight side loading during belt operation

$$S_1 \approx \frac{1030 \cdot P_B}{c_1 \cdot v}$$

$$S_1 \approx \frac{1030 \cdot 23.4}{1.0 \cdot 16.6} \approx 1452 \text{ N}$$

### Dynamic slack side loading during belt operation

$$S_2 \approx \frac{1000 \cdot (1.03 - c_1) \cdot P_B}{c_1 \cdot v}$$

$$S_2 \approx \frac{1000 \cdot (1.03 - 1.0) \cdot 23.4}{1.0 \cdot 16.6} \approx 42 \text{ N}$$


### A) Solution Using the Formula for $S_{a\ dyn}$

#### Dynamic axial force

$$S_{a\ dyn} \approx \sqrt{S_1^2 + S_2^2 - 2 \cdot S_1 \cdot S_2 \cdot \cos\beta}$$

$$S_{a\ dyn} \approx \sqrt{1452^2 + 42^2 - 2 \cdot 1452 \cdot 42 \cdot (-0.99619)} \approx 1494 \text{ N}$$

### B) Graphical Solution



# DESIGN HINTS

## LENGTH TOLERANCES – INSTALLATION AND MAINTENANCE –

### TO ISO 9982



**Table 20: Length Tolerances**

Effective length $L_b$ [mm]	Profile PH	Profile PJ	Profile PK	Profile PL	Profile PM
	Tolerance [mm]	Tolerance [mm]	Tolerance [mm]	Tolerance [mm]	Tolerance [mm]
> 200 ≤ 500	+ 4 - 8	+ 4 - 8	+ 4 - 8		
> 500 ≤ 750	+ 5 - 10	+ 5 - 10	+ 5 - 10		
> 750 ≤ 1000	+ 6 - 12	+ 6 - 12	+ 6 - 12	+ 6 - 12	
> 1000 ≤ 1500	+ 8 - 16	+ 8 - 16	+ 8 - 16	+ 8 - 16	
> 1500 ≤ 2000	+ 10 - 20	+ 10 - 20	+ 10 - 20	+ 10 - 20	
> 2000 ≤ 3000	+ 12 - 24				
> 3000 ≤ 4000				+ 15 - 30	+ 15 - 30
> 4000 ≤ 6000				+ 20 - 40	+ 20 - 40

#### Installation and Maintenance

Geometrically correct designing and power rating of drives with optibelt RB ribbed belts ensures long belt life and a high degree of operating safety.

Since practice has shown that premature failure can very often be traced to faulty installation or maintenance, we recommend that you follow the installation and maintenance instructions listed below.

##### Safety

Before commencing any maintenance work, ensure that all machine components are safely positioned and cannot be altered whilst the work is in progress. It is also important that the manufacturer's safety instructions are carefully followed.

##### Pulleys

The grooves must be in good condition, free from scoring, sharp edges or rust and all dimensions should conform to the relevant standard.

##### Alignment

Shafts and pulleys should be correctly aligned prior to belt installation.

We recommend a maximum tolerance of 0.5° in both planes.

##### Installation of ribbed belts

The centre distance should be reduced prior to the installation of ribbed belts so that they may be fitted in the grooves without undue force. Forcing ribbed belts over the pulley flanges with a tyre lever, screwdriver or the like, must be avoided as the damage this causes to the ribs and low-stretch tension members is often not visible.

##### Ribbed belt tension

Once the calculated axial force has been applied, the tension of the ribbed belts should be checked using our tension gauges and the methods described on pages 48 to 51. The belt should be observed regularly during the first few hours of service. Experience has shown that the belt will need retensioning after between 0.5 and 4 hours at full load to take up the initial belt stretch.

##### Tension/guide idlers

Where possible, the use of tension and guide idlers should be avoided. If this is not possible, refer to the notes on pages 33 to 34 of this manual and follow any instructions given.

##### Maintenance

It is recommended that ribbed belt drives should be regularly inspected. This should include checking and, if necessary, correcting the tension.

Suitable guards must be provided to prevent the intrusion of foreign bodies such as stones, swarf or other material between the pulley and the belt.

optibelt RB ribbed belts do not require any special care. Belt dressing (belt wax and spray) should not be used under any circumstances.

# DESIGN HINTS

## RIBBED BELT WIDTHS



**Table 21**



Number of ribs z	Profile PH [mm]	Profile PJ [mm]	Profile PK [mm]	Profile PL [mm]	Profile PM [mm]
2	3.20	4.68	7.12	9.40	18.80
3	4.80	7.02	10.68	14.10	28.20
4	6.40	9.36	14.24	18.80	37.60
5	8.00	11.70	17.80	23.50	47.00
6	9.60	14.04	21.36	28.20	56.40
7	11.20	16.38	24.92	32.90	65.80
8	12.80	18.72	28.48	37.60	75.20
9	14.40	21.06	32.04	42.30	84.60
10	16.00	23.40	35.60	47.00	94.00
11	17.60	25.74	39.16	51.70	103.40
12	19.20	28.08	42.72	56.40	112.80
13	20.80	30.42	46.28	61.10	122.20
14	22.40	32.76	49.84	65.80	131.60
15	24.00	35.10	53.40	70.50	141.00
16	25.60	37.44	56.96	75.20	150.40
17	27.20	39.78	60.52	79.90	159.80
18	28.80	42.12	64.08	84.60	169.20
19	30.40	44.46	67.64	89.30	178.60
20	32.00	46.80	71.20	94.00	188.00
21	33.60	49.14	74.76	98.70	197.40
22	35.20	51.48	78.32	103.40	206.80
23	36.80	53.82	81.88	108.10	216.20
24	38.40	56.16	85.44	112.80	225.60
25	40.00	58.50	89.00	117.50	235.00
26	41.60	60.84	92.56	122.20	244.40
27	43.20	63.18	96.12	126.90	253.80
28	44.80	65.52	99.68	131.60	263.20
29	46.40	67.86	103.24	136.30	272.60
30	48.00	70.20	106.80	141.00	282.00

Ribbed belts with more than 30 ribs should be divided.  
A space of one rib should be maintained between two ribbed belts.

# DESIGN HINTS

## PROBLEMS – CAUSES – REMEDIES



Problem	Causes	Remedies
<b>Excessive wear of ribs</b> 	Belt tension too low Ingress of foreign body during running Pulley misalignment Faulty pulleys Wrong belt or pulley profile	Check belt tension and correct Fit an effective guard Re-align pulleys Re-machine or replace pulleys Belt and pulley profiles must be correctly matched
<b>Ribbed belt breakage shortly after fitting (belt torn)</b> 	Belt rubbing or catching on protruding parts Drive stalled Drive overloaded Contamination with oil, grease or chemicals	Remove any parts that are in the way; re-align drive Ascertain cause and put it right Check drive conditions and re-dimension Protect drive from environmental influences
<b>Rib breakage and cracks (brittleness)</b> 	Outside idler pulley in use whose position and size is not as recommended Pulley diameter too small Excessive exposure to heat Excessive exposure to cold Abnormal belt slip Chemical influences	Follow Optibelt recommendations, e.g. increase pulley size; replace with inside idler on the slack side of the drive Re-design using recommended minimum pulley diameters Remove or shield from heat source; ensure good ventilation Warm belt before start up Retension drive according to installation instructions; check drive design and modify if necessary Shield drive

# DESIGN HINTS

## PROBLEMS – CAUSES – REMEDIES



Problem	Causes	Remedies
<b>Severe belt vibration</b>	Drive undersized  Drive centre distance significantly longer than recommended  High shock loading  Belt tension too low  Unbalanced pulleys	Check drive design and modify if necessary  Shorten centres, use an inside idler on the belt slack side  Use an inside idler on the slack side  Correct belt tension  Balance pulleys
<b>Ribbed belts cannot be retensioned</b>	 Insufficient allowance for centre distance in drive design  Excessive stretch caused by overloaded drive  Incorrect belt length	Modify drive to allow for the Optibelt recommended take-up  Carry out drive calculation and re-design  Use a shorter belt
<b>Excessive running noise</b>	Poor pulley alignment  Belt tension too low or too high  Drive overloaded	Align pulleys  Check belt tension  Check drive design and modify if necessary
<b>Ribbed belt swelling and softening</b>	 Contamination with oil, grease or chemicals	Protect drive from source of contamination  Clean pulleys with cleaning solvent or benzene before fitting new ribbed belts!

Please contact our Applications Engineering Department in the case of other faults. Please give us as much technical information as possible to assist us with replying to your query.

## DESIGN HINTS ADDITIONAL RANGE



### optibelt TT FREQUENCY METER

Optibelt presents the new generation of TT frequency meter – indispensable for quickly and accurately determining the correct drive belt tension. Now even easier to use and with additional data processing options.

#### Advantages

- Measuring range from 1 Hz to 600 Hz
- No interference in loud and bright environments
- Display of the last measurement value
- Chargeable via USB



### optibelt LASER POINTER II

#### An indispensable aid for belt drives

The user-friendly optibelt LASER POINTER II is a device of proven value, especially for everyday use. The optibelt LASER POINTER II makes it easier to align belt drives.

It also helps to determine the most common causes of drive failures:

- Axial misalignment of the pulley
- Horizontal angular misalignment
- Vertical angular misalignment



### OPTIBELT PULLEY GROOVE GAUGES

Belts and pulleys can be quickly and effortlessly identified with these groove gauges. They also enable pulley groove edges to be tested for angular deviation and wear.



# DATA SHEET

## FOR DRIVE CALCULATION/CHECKING



For trials	<input type="checkbox"/>	New drive	<input type="checkbox"/>	Company										
For pilot series	<input type="checkbox"/>	Existing drive	<input type="checkbox"/>	Street/PO Box										
For production series	<input type="checkbox"/>	Requirement _____ belts/year		Postcode/zip code; town										
				Administrator										
				Department										
				Date										
				Tel. ( ) Email										
				Fitted with:										
				<table border="1"> <thead> <tr> <th>Pieces</th> <th>Effective length</th> <th>Profile</th> <th>Number of ribs</th> <th>Manufacturer</th> </tr> </thead> <tbody> <tr> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	Pieces	Effective length	Profile	Number of ribs	Manufacturer					
Pieces	Effective length	Profile	Number of ribs	Manufacturer										

### Prime Mover

Type (e.g. electric motor, diesel engine 3 cyl.) \_\_\_\_\_

Size of starting load (e.g. starting load = 1.8 normal load) \_\_\_\_\_

Method of starting (e.g. star delta) \_\_\_\_\_

Operation hours per day \_\_\_\_\_

Number of starts \_\_\_\_\_ per hour  per day

Rotational reverses \_\_\_\_\_ per minute  per hour

Power: P normal \_\_\_\_\_ kW

P maximal \_\_\_\_\_ kW

or max. torque \_\_\_\_\_ Nm at n<sub>1</sub> \_\_\_\_\_ rpm

Speed of driver pulley n<sub>1</sub> \_\_\_\_\_ rpm

Position of shafts: horizontal  vertical   
angled  <) \_\_\_\_\_ °

Maximum allowed static shaft loading S<sub>a</sub> max \_\_\_\_\_ N

Effective or outside diameter of driver pulley:

d<sub>b1</sub> \_\_\_\_\_ mm

d<sub>b1</sub> min \_\_\_\_\_ mm

d<sub>b1</sub> max \_\_\_\_\_ mm

Pulley face width b<sub>2</sub> max \_\_\_\_\_ mm

Speed ratio i \_\_\_\_\_

Drive centre distance a \_\_\_\_\_ mm

Tension/guide idler pulley: inside

outside

d<sub>b</sub> \_\_\_\_\_ mm ribbed pulley

d<sub>a</sub> \_\_\_\_\_ mm flat pulley

**Drive Conditions:** Ambient temperature

Exposure to oil

water

acid

dust

### Driven Machine

Type (e.g. lathe, compressor) \_\_\_\_\_

Start: loaded  unloaded

Nature of load: constant  shock  pulsating

Load: P normal \_\_\_\_\_ kW

P maximal \_\_\_\_\_ kW

or max. torque \_\_\_\_\_ Nm at n<sub>2</sub> \_\_\_\_\_ rpm

Speed of driven pulley n<sub>2</sub> \_\_\_\_\_ rpm

n<sub>2</sub> min \_\_\_\_\_ rpm

n<sub>2</sub> max \_\_\_\_\_ rpm

Maximum allowable static shaft loading S<sub>a</sub> max \_\_\_\_\_ N

Effective or outside diameter of driven pulley:

d<sub>b2</sub> \_\_\_\_\_ mm

d<sub>b2</sub> min \_\_\_\_\_ mm

d<sub>b2</sub> max \_\_\_\_\_ mm

Pulley face width b<sub>2</sub> max \_\_\_\_\_ mm

i<sub>min</sub> \_\_\_\_\_ i<sub>max</sub> \_\_\_\_\_

a<sub>min</sub> \_\_\_\_\_ mm a<sub>max</sub> \_\_\_\_\_ mm

in drive slack side

in drive tight side

moveable  (e.g. spring loaded) \_\_\_\_\_

fixed

\_\_\_\_\_ °C/F min.

\_\_\_\_\_ °C/F max.

(e.g. oil mist, droplets) \_\_\_\_\_

(e.g. spray) \_\_\_\_\_

(type, concentration, temperature) \_\_\_\_\_

(type) \_\_\_\_\_

Special conditions: Where the drive has inside or outside idler pulleys, three or more driven pulleys or counter-rotating shafts then a drawing or any other relevant information should be submitted.



**Drive Details:**

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---



## NOTES

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---



## NOTES

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---



## NOTES

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

Owner of any and all copyrights and intellectual property rights as well as other rights of use and exploitation:  
Arntz Optibelt Group, Höxter/Germany.

Any use, exploitation, reproduction, and any transfer to third parties by any means shall require the prior written approval  
of the Arntz Optibelt Group, Höxter/Germany.

Print: 0616



**Optibelt GmbH**  
Corveyer Allee 15  
37671 Höxter  
GERMANY

T +49 (0) 5271-6 21  
F +49 (0) 5271-97 6200  
E info@optibelt.com



[www.optibelt.com](http://www.optibelt.com)